




REMOTE FIRMWARE CONTROL SYSTEM


User interface specification

Accessing the sytstem in a browser





















+256 757 734717 SCIT, 7062 Kampala Uganda







Makerere

Mubende

Entebbe

Lwengo

Kiige-Kamuli

Jinja

Ikulwe

Kidera-Buyende

Controlling Entebbe weather station







Programming the gateway















Upload firmware





Or: Type commands in the terminal below. such as:

mnsabagwa@wimea>\$ update firmaware sinknode

