

Rebel Technology – Stoicheia

- [Manual PDF](#)
-

[Stoicheia \(Στοιχεῖα\) Eurorack Module Manual](#)

Stoicheia: Concise Cheat Sheet

Quick Start

- **Connect Clock IN A/B:** Plug an LFO or clock into the left/right bottom jack(s).
 - **Connect OUT A/B:** Connect left/right OUT jack to your drum or gate-enabled modules.
 - **Middle Switch (both rows):** Center for OFF, UP for Trigger, DOWN for Alternating (see Modes).
 - **Set Knobs:**
 - Bottom: Fills (# of gates per pattern, CCW=1, Center=50%, CW=all)
 - Middle: Length (steps, 1–16, center=8)
 - Top: Rotation (start position; left/right rotates sequence)
-

Panel Controls

Jacks

- **OUT A/B (top left/right jacks):** Rhythmic gate outputs
 - Low: 0V, High: 5.1V
 - Impedance: < 1.1kΩ

- **RESET (middle jack)**: Trigger resets *both* sequences to their start position.
- Input: > 100kΩ
- **CLOCK A/B IN (bottom left/right)**: Clock/trigger for left/right sequence.
- Input: > 100kΩ

Knobs (each sequence, left/right columns)

1. **Top (Rotation)**: Step offset/rotation of sequence start
2. **Middle (Length)**: 1–16 steps, center=8
3. **Bottom (Fills)**: Number of "on" steps (gates), 1–length, center=half, CW=max

Switches

- **Sequence Switch (each sequence, 3-way)**:
 - **UP**: Trigger mode—output follows input clock edges, pulse width matches clock
 - **CENTER**: Off
 - **DOWN**: Alternating/Tied mode—output toggles, holding high until next on-beat
 - **Chained Mode**: Center switch down enables chaining (A then B, outputs merged)
-

Modes

- **Trigger Mode**: Gate outputs follow the input clock width (UP position)
 - **Alternating Mode**: Output toggles on each on-beat (DOWN position)
 - **Chained Mode**: Both sequences run consecutively (via center switch DOWN)
-

Patterns

- **E(x,y)**: x fills, y steps, auto-Euclidean distribution
 - Example: E(3,4) = [x . x x] (Calypso)
 - E(2,5): [x . x . .] (Take Five, Tchaikovsky)
 - E(5,8): [x . x x . x x .] (Cuban cinquillo, Persian)
 - E(7,12): [x . x x . x x . x . x .]
 - E(9,16): [x . x x . x . x x . x . x . x .]
-

Voltage/Current Specs

- **Power**: +12V <10mA, +5V <25mA, -12V 0mA
 - **Output range**: 0V (low), 5.1V (high)
-

Reference

- [Official Manual](#)
 - [Euclidean Patterns Paper by Toussaint \(PDF\)](#)
 - [All source & schematic on Github](#)
-

Hacking / Open Hardware

- **MCU**: ATMega168 (Arduino bootloader, FTDI compatible)
 - **Firmware**: Open source, [see repo](#)
-

Generated With [Eurorack Processor](#)