

Behringer – 173

- Manual PDF
-

[Behringer SYSTEM 100 Series 173 QUAD GATE/MULTIPLES Manual \(PDF\)](#)

Behringer 173 QUAD GATE/ MULTIPLES Quick Reference Cheatsheet

Overview

The **Behringer 173 QUAD GATE/MULTIPLES** is a utility Eurorack module combining four gate process channels and six sets of passive 4-way multiples. It's a simple, but powerful, way to route and manage gate/trigger signals and distribute audio/CV across your modular.

Front Panel Controls & Connections

No Knobs, Buttons, Sliders, or Toggles – This module is patch-programmable only.

1. GATE Section (top 4 rows)

Four individual gate processors, labeled CH1–CH4.

- **GATE IN** (3.5mm jack, left of each section)

- **Type:** Input (accepts gate or trigger)
 - **Input Impedance:** $160\text{k}\Omega$, unbalanced
 - **Voltage Range:** Up to +17 dBu ($\sim 12\text{V}$ p-p, handle at least $\pm 10\text{V}$ typical modular signals)
 - **GATE CV** (3.5mm jack, middle of each section)
 - **Type:** Control Voltage input
 - **Impedance:** $> 50\text{k}\Omega$, unbalanced
 - **Non-Inverting (active high):** gate opens with $\text{CV} > +3\text{V}$
 - **Inverting (active low):** gate opens with $\text{CV} < +1.5\text{V}$
 - **Voltage Range:** Up to 10V p-p
 - **GATE OUT** (3.5mm jack, right of each section)
 - **Type:** Output (passes gate if input and CV are high/truthy)
 - **Output Impedance:** $1\text{k}\Omega$, unbalanced
 - **Voltage Range:** Up to +17 dBu
 - **Frequency Response:** DC to 20 kHz
 - **Output Noise:** $< -90\text{ dBu}$
-

2. MULTIPLES Section (bottom 6 rows)

Six sets of four interconnected jacks per row (A, B, C, D).

- **MULTIPLES A/B/C/D** (total 24x 3.5mm jacks)
 - **Type:** Passive parallel connections
 - **How to use:**
 - Patch an input into A, and the signal appears at B, C, D
 - You can also patch into B, C, or D – they are all parallel
 - **Signal Types:** Passes both audio and CV without clipping
 - **Unbuffered (Passive):** No active circuitry
 - **No voltage drop unless you split to many loads**
-

Voltage and Patch Notes

- **Works with logic, gates, triggers, audio, and CV signals.**
- **Voltage thresholds:**
- **CV Gate:** $> +3\text{V}$ triggers gate (non-inverting), $< +1.5\text{V}$ triggers (inverting)

- **Max Input/Output:** $\sim \pm 10V$ (stated as +17 dBu)
 - **Power draw:** 40mA (+12V), 40mA (-12V)
-

Typical Usage Patterns

- **Gate Channel:**
 - Patch a gate or trigger signal to **GATE IN**
 - Patch a control voltage to **GATE CV** to enable/disable passing the gate
 - Use **GATE OUT** to route the conditioned gate to other modules
 - **Multiples:**
 - Patch any signal (CV or audio) into 'A' (or any jack in the row), and break out to up to 3 other places
-

Reference Summary (All Jacks)

Label	Type	Function	Voltage Range
GATE IN	Input	Gate/trigger input	$\pm 10V$ typical
GATE OUT	Output	Gate/logic output	$\pm 10V$ typical
GATE CV	Input	Control of gate pass-through (internal logic)	0–10V (thresholds: +3V or +1.5V)
MULTIPLES A-D	Input/ Output	Passive mults for CV and audio (any jack is input/output)	Modular levels ($\pm 10V$)

No knobs, buttons, switches or sliders.

For specifics, refer to the [official manual PDF](#).

Generated With Eurorack Processor