

Omnitone – Rosci

- [Manual PDF](#)
-

[Download the Rosci User Manual \(PDF\)](#)

Rosci Eurorack Module Cheat Sheet (Rev 3)

Overview

Rosci is a voltage-controlled digital oscillator module for Eurorack. It excels at generating customizable waveforms through point manipulation, harmonic enhancement, formant compression, and detuning. Can operate as a VCO (audio rate) or LFO (slow modulation).

Controls & Features

Panel Controls

- **Generate Button**
- Generates a new waveform.
- Used in tuning procedure (see below).
- **Knobs** (can be voltage controlled by CV inputs)
- **Complexity:** Number of waveform points (2–20).
- **Roundness:** Interpolation between points.
- **Harmonics:** Adds up to 6 harmonics.

- **Formants:** Compress waveform/mimics vowel sounds.
- **Detune:** Detunes up to a perfect fifth.
- **Coarse & Fine Tune:** Master pitch tuning.

Jumpers (Rear)

- **VCO/LFO Mode Select:** Move jumper to switch between VCO (20Hz–20kHz) and LFO (0.016Hz–20Hz).
-

Inputs & Outputs

Label	Type	Description	Voltage Range
V/OCT	Input	1V/oct pitch input	0V to +10V*
Complexity	Input	CV control, waveform pts	-10V to +10V
Roundness	Input	CV control, interpolation	-10V to +10V
Harmonics	Input	CV control, harmonics	-10V to +10V
Formants	Input	CV control, formant amt	-10V to +10V
Detune	Input	CV control, detune amt	-10V to +10V
OUT	Output	Main waveform out	[Typical Eurorack]

* V/OCT: Typical tolerance ±3 cents.

- All CV inputs are mixed with knob positions.
 - Full sweep of a parameter: 10V.
 - Inputs saturate beyond ±10V.
-

Operation Guide

Basic Use

1. **Patch Output:** Use the OUT jack for audio or modulation signal.
2. **Pitch:** Patch V/OCT for pitch tracking. Use 0V–10V; prefer 2V–8V for best tuning.
3. **Shape:** Shape sound with Complexity, Roundness, Harmonics, Formants, Detune (knobs or CV).
4. **Trigger:** Press Generate to create new waveform.

Mode Switch (LFO/VCO)

1. **Power Off** your system.
2. **Move rear jumper** to “LFO” pins for LFO mode (0.016–20Hz) or “VCO” pins for VCO mode (20Hz–20kHz).
3. **Power On** to use.

Tuning Procedure

1. Set Coarse/Fine tune to minimum.
 2. Hold Generate on power up → lights flash red.
 3. Send V/OCT 2V (not 0V/10V), press Generate.
 4. Lights flash green. Send 2V higher, press Generate.
 5. Lights turn multi-color; module exits tuning.
-

Safety Notes

- Always power off your case when installing or moving Rosci.
 - Red stripe on power cable to -12V.
-

Contact & Support

- Omnitone.ca
- info@omnitone.ca

- Instagram: @Omnitone_music
-

Generated With Eurorack Processor