Guideline, AutoCAD Layer Standard for Ascenx Drawing Template

Presents to DSE Division 06/10/2010

ASCENX

Index

- Layers standard and Drawing format style.
 - Layer standard
 - □ Format style of drawing
- Template user guide
 - □ Using Template
 - □ Update information for BOM, REV Table
 - □ Using Block library




Ascenx's DSE Layer Standard

No	Layer Name	Color No.	Color	Linestyle	Lineweight	Description
				-		Wires, Cable, Ribbon cable, Connector, Switch, Fuse,
1	Components	7	white	Continuous	0.18	Ring, Heatshrink Tubing, Crimp, Tie wrap, Label,
2	HiddenS	6	magenta	Hidden2	0.18	Show hiden line of the views or related objects
3	HiddenM	6	magenta	Hidden	0.18	Show hiden line of the views or related objects
4	HiddenL	6	magenta	HiddenX2	0.18	Show hiden line of the views or related objects
5	CenS	1	red	Center2	0.13	Show center line or center mark of circle, cylinder or related objects
6	CenM	1	red	Center	0.13	Show center line or center mark of circle, cylinder or related objects
7	CenL	1	red	CenterX2	0.13	Show center line or center mark of circle, cylinder or related objects
8	Dims	3	green	Continuous	0.13	Make dimension and related objects
9	Balloon	7	white	Continuous	0.18	Make note (text) and boundary line of balloon
10	Break line	7	white	Continuous	0.13	Limited line when break the length line to 2 part
11	Text-T	2	yellow	Continuous	0.18	Text for Title block
12	Text-N	7	white	Continuous	0.18	Text for Notes, Description, Detaile note
13	REV	2	yellow	Continuous	0.18	Updates revision 01, 02, 03,
14	REV-Table	2	yellow	Continuous	0.18	Out line of REV table
15	BOM Table	2	yellow	Continuous	0.18	Out line of BOM table
16	Hatch	7	white	Continuous	0.18	Make section or filled the shape
17	Symbol	7	white	Continuous	0.18	Symbol (Balloon, Block, Attributed block,
18	Boder	7	white	Continuous	0.25	Boder for Drawing boder and out line of title block
19	Title Block	7	white	Continuous	0.18	Title Block
20	Logo	RGB 32,67,115	RGB 32,67,115	Hatch-Solid	0.18	Ascenx's Logo (From Image)

Note: Must use layers which were created for all Ascenx's drawing




Layer Standard in AutoCAD





Format styles of Drawing

Dimens	sion Style Manag	er
1	Dimension style	Ascenx style
2	Dimemsion line	Green
3	Extension line	Green
4	Baseline spacing	0.646
5	Extend beyond dims line	0.306
6	Offset from origin	0.10625
7	Arrow head	Closed filled
8	Arrow size	0.1875
9	Text style	Style 1
10	Text height	0.156




Note: Do not change parameter while they are not approve yet.




Format styles of Drawing (cont. 1)

Text St	yle Manager	
1	Text Type	TextStyle 1
2	Font	Simplex
3	Height (All)	0.12
4	Height (Inside title block)	0.0825



MultiL	eader Style Ma	nager
1	MultiLeader Style	Ascenx style
2	Туре	Straight
3	Arrow head	Closed filled
4	Arrow size	0.18
5	Text height	0.156







Format styles of Drawing (cont. 2)

Table Style for BO		OM Table
1	Туре	Ascenx style-BOM
2	Text type	TextStyle 1_Ascena
3	Font	Simplex
4	Height	0.1

Table	Style for REV Tab	ole
1	Type	Ascenx style_REV
2	Text type	TextStyle 1_Ascenx
3	Font	Simplex
4	Height	0.1




Balloor	n or Note for Qua	ntity
Circle Dia.	Text Height	Text style
0.55	0.256	Simplex
0.35	0.156	Simplex





Using Template

Copy file TEMPLATE, AUTOCAD DRAWING, ASCENX (B/D SIZE, SHEET_01/02.dwt) to folder AutoCAD as below:




Using these template when create 1 new drawing (Command: New) by choose Ascenx template



Update information for Title Block


- ☐ Go to menu FILE\Drawing Properties ← to update all information for title block such as DWG No., Drawn, Date,...
- ☐ Push "Save" button to refresh & update info. In Title block



Note: May use function to create other parameters for drawing



Update information for BOM & REV




	А	В	С	D	Е
1			REVISIONS		
2	ECO	REV	DESCRIPTION	APPROVED	DATE
3	I				

All in information input to BOM or REV Table same with using Excel.



Using Ascenx attribute block library

Shortcut command: I



<u>Note</u>: Need update more block for drawing such as Connector, Terminal ring, Power supply,...



Using Plot for Ascenx style

Parameter for printing:

- Plot style table (pen assignment): monochrome.ctb
- □ What to plot: Display Window
- □ Plot scale: fit to paper
- □ Check ☑ Center the plot
- ☐ Check Plot ☑ with styles (include Plot object with lineweights.

How to setup a Ascenx Ploter/Printer (PDF file is same)

- □ Chose plotter/printer -> properties
- Choose Device and Document Setting tab -> Custom properties
- Choose Paper/Quality tab -> Choose paper size and direction of paper -> OK
- □ Save as printer with name "Ascenx Printer 5200" or others → OK.
- □ Choose Save changes to the following file → OKSave as printer with named "Ascenx Printer 5200" → OK.
- □ Choose Apply to Layout
- If using pdfFactory Pro, pls set Metrics (Left, Top, Right, Bottom is 0.1")

www.Ascenx.com



THANK YOU

ASCENX Technologies
1905 Tarob Court
Milpitas, CA 95035
Tel. 408-945-1997
Email. sales@ascenx.com

e.Town 2 bldg., suite 608 364 Cong Hoa Street, Ward 13 Tan Binh District, HCMC, Vietnam Tel. +84-8.297.1075

BACKUP

