#### Chapter 3

# **Transceiver, Noise and Nonlinear Distortion**

# Chapter 3

# Transceiver, Noise and Nonlinear Distortion



Department of Telecommunication Engineering Faculty of Electrical and Electronics Engineering Ho Chi Minh city University of Technology

#### **Textbook:**

Steven J. Franke, *Wireless Communication Systems*, UIUC Chapter 2, 10

#### **References:**

B. Razavi, *RF Microelectronics*, Upper Saddle River, Prentice Hall, Second Edition, 2011 (Chapter 2)

2021 FEEE - HCMUT 1 Radio Communication Circuits © 2021 FEEE - HCMUT 2 Radio Communication Circ

# Transceiver, Noise and Nonlinear Distortion

#### **Outline**

- ☐ Introduction and Historical Progression
- RF Transceiver
- Noise
- **■** Nonlinear Distortion

# 1. Introduction and Historical Progression

 The history of radio communication begins at the end of the 19'th century, when Italian inventor Guglielmo Marconi developed the first practical radio communication system using spark-gap radio transmitters and a nonlinear circuit element, called a "coherer", as a detector at the receiving end of the link.




- His most famous accomplishment was demonstration of transatlantic wireless communications, in 1902, when the Morse-code letter "S" (dot dot dot) was transmitted from England, and received in Newfoundland.
- Wireless telegraphy transmission using spark-gap transmitters used the broadband damped oscillations generated when the DC current in an LC circuit is suddenly interrupted.

2/2/27 FEEE - HCMU 1 3 Kadio Communication Circuits © 2/27 FEEE - HCMU 1 4 Radio Communication Circuits


# 1. Introduction and Historical Progression

#### **Tuned Detector/Demodulator**




# 1. Introduction and Historical Progression

#### Tuned Radio Frequency (TRF) Receiver



· Very popular receiver architecture that was employed in the 1920's for AM broadcast receivers



#### Require:

- Tunable
- High-gain
- Narrow-bandwidth
- Filter/amplifier

A regenerative receiver employing a regenerative amplifier in front of a demodulator

# 1. Introduction and Historical Progression


## Genesis of the Superheterodyne Receiver

- > Superheterodyne receiver was invented by Edwin Armstrong in 1917
- Armstrong became a member of the U.S. Army Signal Corps during World War I.
   Involved with efforts to find a way to detect enemy airplanes from a distance
- He knew that it might be possible to detect the electromagnetic emissions from the spark plugs in the engine.
- The problem was that the emissions were strongest at the (then) unusually high frequencies above a few MHz.
- Triodes of the day had very little gain at such high frequencies, so Armstrong hit on the idea of employing the heterodyne principle to shift the high-frequency signals to a lower frequency, where they could be more efficiently amplified and filtered.
- Once he decided to incorporate the heterodyne concept into his receiver, it became
  possible to heterodyne any signal of interest, regardless of its frequency, to a fixed
  intermediate frequency (IF). Selective filtering, and high-gain amplification could be
  done at the fixed IF.

# 1. Introduction and Historical Progression

#### **Characteristics of Practical Filters**

 Losses in the components used to implement filter networks set a lower limit on the bandwidth that can be achieved in a bandpass filter.



- ✓ In many cases, the resonant circuit Q is limited by the Q of the inductor.
- ✓ For miniature inductors, Q's may be limited to values in the range 10-100, whereas inductors implemented using spirals of metallization in integrated circuits typically have very low Q, often <10.
- ✓ Fractional BW is 1/Q
- ✓ Generally speaking, LC filters with fractional bandwidths smaller than around 0.01 tend to become impractical.
- ➤ Transmission-line and cavity resonator filters -- > difficult to tune
- ➤ Filters based on piezoelectric devices Quartz-Crystal Filter, Ceramic Filter → high Q, but expensive and low frequencies, not tunable
- ➤ SAW filters → high Q, but expensive, not tunable

© 2021 FEEE - HCML


Radio Communication Circ

024 EEEE HOMUT

Padia Co

# 1. Introduction and Historical Progression


#### Filter limitations dictate carrier-frequency conversion




#### Can we select an RF wanted signal while completely filter the Interferers at RF frequency?

- ✓ First, the filter must provide a very high Q
- ✓ Second, the filter would need to have a variable and precise center frequency.
- ✓ Can we select the channel at RF frequency?
- The bandwidth of CDMA channel is 1.25 MHz, and the center frequency is approximately 1900 MHz. A fractional bandwidth of 1.25/1900 of 0.00066 is required.
- ✓ GSM: 200K/900M

# 2. RF Transceiver



- ☐ A Transceiver consists of a Transmitter and a Receiver
- □ RF/Microwave transceiver can be divided into two sections:



- RF/Microwave Section analog, high frequencies
- Baseband Section mostly digital today (DSP), low frequencies

2021 FEEE - HCMU

9

Radio Communication Circuits


2021 FEEE - HCMUT

10

Radio Communication Circui


## 2. RF Transceiver

#### □ Typical Digital Receiver



#### 2. RF Transceiver

#### □ Typical Digital Transmitter




© 2021 FEEE - HCMUT 11 Radio Communication Circuits © 2021 FEEE - HCMUT 12 Radio Communication Circ

#### 2. RF Transceiver

#### 2. RF Transceiver - Receiver

#### ☐ What are the functions of each building block?




(b) Superheterodyne Receiver

erodyne: combine (a high-frequency signal) with another to produce a lower frequency in this way

21 FEEE - HCMUT 13

Radio Communication Circ

☐ Channel Selection and Band Selection




- > It is extremely difficult to select channel at RF frequency due to high-Q RF filter.
- Channel selection must be deferred to some other point where center frequency is lower and hence required Q is more reasonable
- Most receiver front ends do incorporate a "band-select" filter
- Constant IF: LO frequency is variable, all RF channels within the band of interest translated to a single value of IF.

# 2. RF Transceiver - Receiver

#### **Superheterodyne Receiver**

- Conversion to a fixed frequency takes advantage of the fact that it is much easier to realize narrow-band filters and stable, high-gain amplifiers if the frequency of operation doesn't change.
- $\succ$  The IF frequency is fixed, the LO frequency is adjusted to select different channel.




# 2. RF Transceiver - Receiver

#### **Mixer Fundamentals**

If 
$$x(t) = A\cos\omega_1 t$$
  
 $y(t) = B\cos\omega_2 t$ 
 $x(t)$ 

Then the output is



2021 FEEE - HCMUT

15

Radio Communication Circuit

© 2021 FEEE - HCMU


16

Radio Communication Circu

#### 2. RF Transceiver - Receiver


#### Mixer in a Transmitter (Up-conversion Mixer)

 In a transmitter, a mixer is used to mix with IF signal to up-convert the signal frequency for efficient radio-wave transmission from antenna.




# 2. RF Transceiver - Receiver

#### Mixer in a Receiver (Down-conversion Mixer)




Mixer application (frequency conversion)



#### 2. RF Transceiver - Receiver


#### **General Considerations**

- > The main function of a receiver is the demodulation of a wanted signal (channel) in the presence of undesired interferers and noise.
- > Due to the strong attenuation during air transmission, the RF signal has to be amplified and recovered.
- Taking into account scenarios with varying attenuation, a wide dynamic range is required for the detection of signals with high data-rates.




# **BPF First or LNA First?**

- □ Trade-off between suppressing inter-modulation products due to interferers vs. noise figure
- BPF first: better interferer rejection, but higher noise figure due to the insertion loss of the filter
- □ LNA first: better noise figure, receiver can be desensitized due to interferers
- □ Interferers are bigger problem, so BPF first is adapted in all receivers



### 2. RF Transceiver - Receiver




Two spectra located symmetrically around  $\omega_{LO}$  are downconverted to the IF

### 2. RF Transceiver - Receiver

#### **Superheterodyne Receiver**


#### Using Image Reject Filter



 $\omega_{im} = \omega_{in} + 2\omega_{IF} = 2\omega_{LO} - \omega_{in}$ 

#### 2. RF Transceiver - Receiver


# Image Rejection



- The most common approach is to precede the mixer with an "imagereject filter"
- The IRF should exhibits the low loss in the desired band and high attenuation in the image band.
- A filter with high image rejection typically appears between the LNA and the mixer so that the gain of the LNA lowers the filter's contribution to the receiver noise figure.
- The linearity and selectivity required of the image-reject filter have dictated passive, off-chip implementations.

#### 2. RF Transceiver - Receiver

# ■ Image Rejection




#### Example - FM Broadcast Receiver

The FM broadcast band covers 88 - 108 MHz. The channels are separated by 200 kHz and are assigned to odd multiples of 100 kHz. In almost all cases the IF frequency is chosen to be 10.7 MHz. As in the previous example "high-side" LO is often used, i.e., the LO tunes from 98.7 to 118.7 MHz.


Notice that the IF used for FM broadcast receivers is substantially higher than that used for AM receivers. This choice is motivated by the fact that the image frequency is separated from the desired carrier frequency by 2fIF. Generally speaking, in order tomake the preselector filter relatively easy to build and tune, the IF frequency must be raised as the carrier frequency increases.

# ☐ Image Rejection versus Channel Selection



- As noted, the desired channel and the image have a frequency difference of  $2\omega_{IF}$ . Thus, to maximize image rejection, it is desirable to choose a large value for  $\omega_{IF}$  i.e., a large difference between  $\omega_{in}$  and
- $\triangleright$  How large can  $2\omega_{IF}$  be? Recall that the premise in a heterodyne architecture is to translate the center frequency to a sufficiently low value  $\omega_{IF}$  so that channel selection by means of practical filters becomes feasible.
- → Image Rejection Channel Selection Trade-Off

☐ Image Rejection versus Channel Selection



2. RF Transceiver - Receiver

A high IF allows substantial rejection of the image.



A low IF helps with the suppression of in-band interferers.

### 2. RF Transceiver - Receiver


## ☐ Image Rejection versus Channel Selection

- The trade-off between image rejection and channel selection in the heterodyne architecture often proves quite severe: if the IF is high, the image can be suppressed but complete channel selection is difficult, and vice versa.
- To resolve this issue, the concept of heterodyning can be extended to multiple down-conversions, each followed by filtering amplification

**Double-conversion SupperHeterodyne Receiver** 

#### 2. RF Transceiver - Receiver

#### **□** Double-conversion Supper Heterodyne Receivers



- In a double-conversion receiver the bandwidth of the first IF filter would be chosen to reject 'secondary" image frequencies within the first IF bandwidth.
- A secondary image would be an undesired frequency within the passband of the first IF filter that could be mixed into the second IF filter's passband.
- The second IF filter's bandwidth would usually be just wide enough to pass the entire spectrum of the desired signal.




#### 2. RF Transceiver - Receiver

#### ☐ Double-conversion Supper Heterodyne Receivers




- After amplification and image-reject filtering, spectrum of C obtained
- Sufficiently linear mixer translates desired channel and adjacent interferers to first IF (Point D)




- (Point E)
- Spectrum is translated to second IF. (Point F)

#### 2. RF Transceiver - Receiver

#### **□** Double-conversion Supper Heterodyne Receivers



- BPF<sub>4</sub> suppresses the interferers to acceptably low levels (Point G)
- An optimum design scales both the noise figure and the IP3 of each stage according to the total gain preceding that stage.




# □ The problems associated with the image rejection have motivated designers to invent other receiver architecture and smart techniques for the rejection of the image frequency.

- Receiver architectures
  - Heterodyne receiver image problem
  - Super-heterodyne receiver more circuits, more power
  - Image-reject receivers
    - ✓ Harley receiver
    - ✓ Weaver architecture
  - ➤ Homodyne (direct conversion, zero-IF) DC offset
  - > Low IF
  - Digital IF

#### 2. RF Transceiver - Receiver

### ■ Direct-conversion Receiver – (Zero-IF)

> The idea is to translate the RF signal directly to zero-IF frequency.




2021 FEEE - HCMUT 31 Radio Communication Circuits © 2021 FEEE - HCMUT 32 Radio Communication Circuits

#### 2. RF Transceiver - Receiver

#### ■ Direct-conversion receivers

- > Advantage:
  - o The channel filtering can be performed by a low-pass filter.
  - Eliminating the image problem. Hence, no external high-Q image reject filter is required making fully integrated solutions feasible.
- ➤ The zero-IF approach seems to be superior compared with other architectures. However, the following issues impede its widespread use in today's radios.
  - The RF carrier and the local oscillator are at the same frequency. Thus, LO leakage to the mixer input can lead to self mixing resulting in a timevarying DC offset at the output of the mixer.
  - This DC offset may corrupt the signal and can lead to a saturation of the following stages thereby significantly degrading the upper boundary of the dynamic range. Consequently, sophisticated offset cancellation techniques are required in practical implementations.
  - The flicker noise of the active devices becomes significant at low frequencies. Thus, low noise amplification and active filtering is difficult for zero-IF topologies degrading the lower limit of the dynamic range.

#### 2. RF Transceiver - Receiver



- > Transceivers consist of both a receiver and a transmitter.
- In many cases, a transceiver needs only one multifunctional VCO since it may be used for both the receiver and transmitter.
- SPDT (Single Pole Double Throw) switches can be employed to change between the receive- and transmit- modes.
- ➤ These switches exhibits the additional losses of around 0.5–2 dB, which directly add to the overall noise figure in the receiver and reduce the effective PA power.

© 2021 FEEE - HCMUT 34 Radio Communication Circuits © 2021 FEEE - HCMUT 34 Radio Communication Circu

#### 2. RF Transceiver - Receiver

#### **Example - AM Broadcast Receiver**

- ➤ A typical AM broadcast receiver covers the frequency range 540 1700 kHz.
- ➤ AM broadcast stations in the U.S. are assigned frequencies that are integer multiples of 10 kHz, therefore the adjacent channel separation is 10 kHz. The IF frequency is very often chosen to be 455 kHz.

Local oscillator tuning range: 1. 995 kHz to 2155 kHz 2. 85 kHz to 1245 kHz

# 2. RF Transceiver - Receiver

#### **Example - FM Broadcast Receiver**


- The FM broadcast band covers 88 108 MHz. The channels are separated by 200 kHz and are assigned to odd multiples of 100 kHz.
- ➤ In almost all cases the IF frequency is chosen to be 10.7 MHz.
- > As in the previous example "high-side" LO is often used, i.e., the LO tunes from 98.7 to 118.7 MHz. Why?
- Notice that the IF used for FM broadcast receivers is substantially higher than that used for AM receivers.
- This choice is motivated by the fact that the image frequency is separated from the desired carrier frequency by 2fIF.
- Generally speaking, in order to make the preselector filter relatively easy to build and tune, the IF frequency must be raised as the carrier frequency increases.

HW: 4, 5, 6, 7, 8, 9, 10, 12, 14, 15, 18 (Image-reject mixer)

# 3. Noise in RF/Microwave Systems

> The effect of noise is critical to the performance of most RF/Microwave communications, radar, and remote sensing systems.

> Noise ultimately determines the threshold for the minimum signal that can be reliably detected by a receiver.



Noise power in a receiver will be introduced from:

- ✓ The external environment through the receiving antenna External Noise
- ✓ Internal circuits of receivers Internal Noise

2024 FEEE HOMUT

07

dio Communication Circuits

24 EEEE HOMUT


Radio Communication Circui

### 3. Noise in RF/Microwave Systems

<u>External noise</u> may be introduced into a system either by a receiving antenna or by electromagnetic coupling.

Some sources of external RF noise include the following:

- ✓ Thermal noise from the ground
- ✓ Cosmic background noise from the sky
- ✓ Noise from stars (including the sun)
- ✓ Lightning
- ✓ Gas discharge lamps
- ✓ Radio, TV, and cellular stations
- ✓ Wireless devices
- ✓ Microwave ovens
- ✓ Deliberate jamming devices



Noise vs. Interferer

#### 3. Noise in RF/Microwave Systems

<u>Internal Noise</u> generated in a device or component is usually caused by random motions of charges or charge carriers in devices and materials.

Such motions may be due to any of several mechanisms, leading to various types of noise:

- Thermal noise is the most basic type of noise, being caused by thermal vibration of bound charges. It is also known as Johnson or Nyquist noise.
- > Shot noise is due to random fluctuations of charge carriers in an electron tube or solid-state device.
- ➤ Flicker noise occurs in solid-state components and vacuum tubes. Flicker noise power varies inversely with frequency, and so is often called 1/ f -noise.

2021 FEEE - HCMUT

39

Radio Communication Circuits

2021 FEEE - HCMU

40

Radio Communication Circu

#### 3. Noise in RF/Microwave Systems


#### **Noise in Bipolar Transistors**

➤ Bipolar transistors contain physical resistances in their base, emitter, and collector regions, all of which generate thermal noise. Moreover, they also suffer from "shot noise" associated with the transport of carriers across the base-emitter junction.


In low-noise circuits, the base resistance thermal noise and the collector current shot noise become dominant. For this reason, wide transistors biased at high current levels are employed.

#### 3. Noise in RF/Microwave Systems

# Noise in resistor: Noise as a Random Process



> The average current remains equal to  $V_B/R$  but the instantaneous current displays random values




T must be long enough to accommodate several cycles of the lowest frequency.

## 3. Noise in RF/Microwave Systems

# ☐ Noise of Resistor


The noisy resistor can be replaced with a <u>Thevenin equivalent circuit of a noiseless resistor and a random-noise voltage generator v<sub>η</sub></u>



Equivalent circuit of a noisy resistor delivering maximum power to a load resistor through an ideal bandpass filter

 $k = 1.380 \times 10-23$  J/K is Boltzmann's constant.


The maximum power transfer from the noisy resistor to a load resistance  $(Z_L)$ 




\* when 
$$\begin{cases} T = 290^{\circ}K, B = 1Hz \implies P_n = kTB = -174 \text{ (dBm)} \\ T = 290^{\circ}K, B = 1kHz \implies P_n = kTB = -144 \text{ (dBm)} \\ T = 290^{\circ}K, B = 1MHz \implies P_n = kTB = -114 \text{ (dBm)} \end{cases}$$


### 3. Noise in RF/Microwave Systems

**Signal to Noise Ratio** (SNR) =  $\frac{\text{Desired signal power}}{\text{Undesired noise power}}$ 






: Circuit noise added to input noise




**Noise Figure:** measures the degradation in the signal-to-noise ratio between the input and output of the component




ı Circuits © 2021 FEEE - HCMUT 44 Radio Communication Circuit

# 3. Noise in RF/Microwave Systems


# Signal to Noise Ratio $(SNR) = \frac{\text{Desired signal power}}{\text{Undesired noise power}}$






**Noise Figure:** measures the degradation in the signal-to-noise ratio between the input and output of the component

# 3. Noise in RF/Microwave Systems



### 3. Noise in RF/Microwave Systems

# Noise Figure of Cascaded Stages



Friis equation

$$NF = NF_1 + \frac{NF_2 - 1}{G_1} + \frac{NF_3 - 1}{G_1G_2} + \dots + \frac{NF_n - 1}{G_1G_2...G_{n-1}}$$

 $NF_n$  is the noise factor in linear (not in dB) of the n-th stage  $G_n$  is the power gain in linear (not in dB), too.

What do we learn from the Friis equation?


#### 3. Noise in RF/Microwave Systems

# **Noise Figure Exercise**

1. In a two -stage system, show that:

$$NF = NF_1 + \frac{NF_2 - 1}{G1}$$

2. Using Friis equation, find the total NF of a system having the BPF (with the insertion loss of L) as the first block.
What is your conclusion from the result?



#### **Sensitivity:**

Sensitivity Min. detectable signal by the receiver according to a fixed S/N determined by the BER

$$NF = \frac{SNR_{in}}{SNR_{out}} = \frac{P_{in}}{P_{\textit{noise,in}}} \cdot \frac{1}{SNR_{out}}$$

$$sensitivity = P_{in.min} = NF.P_{noise.in}.SNR_{out}$$

$$P_{in \min} = NF.(KTB).SNR_{out \min}$$

$$10Log(KTB) = -174 + 10Log(B)$$

$$P_{m,\min}(dBm) = NF\Big|_{dB} - 174 dBm/Hz + 10 Log B + SNR_{out,\min}\Big|_{dB}$$


Noise floor = Total integrated noise of the system

$$F = NF|_{dB} - 174 dBm/Hz + 10LogB$$

$$NF = \frac{N_o}{GN_{in}} = \frac{GN_{in} + N_o}{GN_{in}} = \frac{N_{in} + \frac{N_o}{G}}{N_{in}}$$

Required Receiver Sensitivity – A Qualitative View

What is the required receiver NF to achieve a certain level of sensitivity?



$$NF = \frac{N_o}{GN_{in}} = \frac{GN_{in} + N_a}{GN_{in}} = \frac{N_{in} + \frac{N_a}{G}}{N_{in}}$$

- To find Receiver NF
  - Transmit Power FCC regulated
  - Path loss
  - Receiver sensitivity govern by standards and applications
  - Required SNR depends on BER requirement and modulation scheme
  - Noise floor thermal noise or circuit noise limited depending on the modulation schemes

2021 FEEE - HCMUT

...


Radio Communication Circu

2021 FEEE - HCMU

50

adio Communication Circu

### 4. Nonlinear Distortion in RF/Microwave Systems



The input/output characteristic of a memoryless nonlinear system can be approximated with a polynomial


$$V_{out} = V_{DD} - I_D R_D$$

$$= V_{DD} - \frac{1}{2} \mu_n C_{ox} \frac{W}{L} (V_{in} - V_{TH})^2 R_D \qquad \mathbf{V_{in}} \sim \mathbf{V_{in}} \sim \mathbf{V_{in}}$$

In this idealized case, the circuit displays only second-order nonlinearity

# 4. Nonlinear Distortion in RF/Microwave Systems

# **■** Nonlinear Distortion



- **Harmonic generation** (multiples of a fundamental signal)
- **➢ Gain Compression** (gain reduction in an amplifier)
- Desensitization Blocking
- ➤ Inter-modulation Distortion (products of a two-tone input signal)


4. Nonlinear Distortion in RF/Microwave Systems

# 4. Nonlinear Distortion in RF/Microwave Systems

### Effects of Nonlinearity: Harmonic Distortion

$$\begin{aligned} x(t) &= A\cos\omega t, \text{ then} \\ y(t) &= \alpha_1 A\cos\omega t + \alpha_2 A^2 \cos^2\omega t + \alpha_3 A^3 \cos^3\omega t \\ &= \alpha_1 A\cos\omega t + \frac{\alpha_2 A^2}{2}(1+\cos2\omega t) + \frac{\alpha_3 A^3}{4}(3\cos\omega t + \cos3\omega t) \\ &= \frac{\alpha_2 A^2}{2} + \left(\alpha_1 A + \frac{3\alpha_3 A^3}{4}\right)\cos\omega t + \frac{\alpha_2 A^2}{2}\cos2\omega t + \frac{\alpha_3 A^3}{4}\cos3\omega t. \end{aligned}$$

# Gain Compression: 1-dB Compression Point



Output falls below its ideal value by 1 dB at the 1-dB compression point

> Peak value instead of peak-to-peak value

Pin = ? , Pout = ? Voltage gain ? Power Gain ?

nth harmonic grows in proportion to *An* 

Even-order harmonics result from  $\alpha_i$  with even j


1 FFFF - HCMIT 59 Padio Communication (

Radio Communication Circ


## 4. Nonlinear Distortion in RF/Microwave Systems

## 4. Nonlinear Distortion in RF/Microwave Systems

#### Nonlinear Distortion - Harmonic Generation and Gain Compression



#### Gain Compression: Effect on FM and AM Waveforms



- > FM signal carries no information in its amplitude and hence tolerates compression.
- AM contains information in its amplitude, hence distorted by compression

55

dio Communication Circuits


2021 FEEE - HCMUT

RR

dio Communication Circuit

#### 4. Nonlinear Distortion in RF/Microwave Systems

# Gain Compression: Desensitization - Blocking



#### Desensitization: the receiver gain is reduced by the large excursions produced by the interferer even though the desired signal itself is small.


### 4. Nonlinear Distortion in RF/Microwave Systems

Weak desired signal

## Nonlinear Distortion — Desensitization and Blocking

Effect of system nonlinearity on the capability of the receiver to extract the weak signal from the strong interferers (Blockers)

By checking the desired frequency  $\boldsymbol{\omega}$ 



$$y(t) = (\alpha_1 A_1 + \frac{3}{4} \alpha_3 A_1^3 + \frac{3}{2} \alpha_3 A_1 A_2^2) \cos \omega_1 t$$
, where  $\alpha_3 < 0$ 

for  $A_1 \ll A_2$ 

 $y(t) = (\alpha_1 + \frac{3}{2}\alpha_3 A_2^2) A_1 \cos \omega_1 t$ 


The gain is compressed now by the effect of the strong interferer. We call this interferer (Blocking signal)

⊋ 2021 FEEE - HCMUT 57 Radio Communication Circuits © 2021 FEEE - HCMUT 58 Radio Communication Circuits

# 4. Nonlinear Distortion in RF/Microwave Systems

Effects of Nonlinearity: Intermodulation—Recall Previous Discussion

#### So far we have considered the case of:



# 4. Nonlinear Distortion in RF/Microwave Systems

#### Effects of Nonlinearity: Inter-modulation Distortion (IMD)

assume  $x(t) = A_1 \cos \omega_1 t + A_2 \cos \omega_2 t$ 

Thus

 $y(t) = \alpha_1(A_1\cos\omega_1 t + A_2\cos\omega_2 t) + \alpha_2(A_1\cos\omega_1 t + A_2\cos\omega_2 t)^2 + \alpha_3(A_1\cos\omega_1 t + A_2\cos\omega_2 t)^3$ 

#### Intermodulation products:

$$\omega = 2\omega_1 \pm \omega_2 : \frac{3\alpha_3 A_1^2 A_2}{4} \cos(2\omega_1 + \omega_2)t + \frac{3\alpha_3 A_1^2 A_2}{4} \cos(2\omega_1 - \omega_2)t$$

$$\omega = 2\omega_2 \pm \omega_1 : \frac{3\alpha_3 A_1 A_2^2}{4} \cos(2\omega_2 + \omega_1)t + \frac{3\alpha_3 A_1 A_2^2}{4} \cos(2\omega_2 - \omega_1)t$$

#### **Fundamental components:**


$$\omega = \omega_1, \ \omega_2: \ \left(\alpha_1 A_1 + \frac{3}{4}\alpha_3 A_1^3 + \frac{3}{2}\alpha_3 A_1 A_2^2\right) \cos \omega_1 t + \left(\alpha_1 A_2 + \frac{3}{4}\alpha_3 A_2^3 + \frac{3}{2}\alpha_3 A_2 A_1^2\right) \cos \omega_2 t$$

## 4. Nonlinear Distortion in RF/Microwave Systems


# 4. Nonlinear Distortion in RF/Microwave Systems

#### Nonlinear Distortion - Inter-modulation Distortion (IMD)

=>  $(m\omega_1 \pm n\omega_2)$  terms: (m+n)th order IM products m, n = 1, 2, 3, 4...



Intermodulation Product Falling on Desired Channel



- A received small desired signal along with two large interferers
- Intermodulation product falls onto the desired channel, corrupts signal.

2021 FEEE - HCMUT

04

idio Communication Circuits

2021 FEFF - HCMUT

Output

62


dio Communication Circuit

#### 4. Nonlinear Distortion in RF/Microwave Systems

#### Example of Intermodulation

Suppose four Bluetooth users operate in a room as shown in figure below. User 4 is in the receive mode and attempts to sense a weak signal transmitted by User 1 at 2.410 GHz. At the same time, Users 2 and 3 transmit at 2.420 GHz and 2.430 GHz, respectively. Explain what happens.

Solution:




Since the frequencies transmitted by Users 1, 2, and 3 happen to be equally spaced, the intermodulation in the LNA of  $R_{X4}$  corrupts the desired signal at 2.410 GHz.

### 4. Nonlinear Distortion in RF/Microwave Systems

Intermodulation: Third Intercept Point

is the point where the output power at  $\omega_1$  equals to output power at  $(2\omega_1 - \omega_2)$ 



 IP3 is not a directly measureable quantity, but a point obtained by extrapolation

2021 FEEE - HCMUT

63

Radio Communication Circuits

.....


64

Radio Communication Circu

#### 4. Nonlinear Distortion in RF/Microwave Systems

# Nonlinear Distortion — Inter-modulation Distortion (IMD)

3rd order intercept point: IP3



• linear output power  $P_o(dBW) = 10 \log \left\{ \frac{(k_1 A)^2}{2R} \right\} = 10 \log \left\{ \frac{(A)^2}{2R} \right\} + 10 \log(k_1)^2 = P_i + \underbrace{10 \log(k_1)^2}_{\text{a constant}}$   $=> P_o: P_i \text{ line} \quad \text{slope 1:1}$ 

# 4. Nonlinear Distortion in RF/Microwave Systems

# $\underline{\textbf{Nonlinear Distortion} - \textbf{Inter-modulation Distortion (IMD)}}$

3rd order intercept point: IP3

• 3rd-order IMD output power

$$P_{(2\omega_{1}-\omega_{2})} = 10 \log \left\{ \frac{(\frac{3}{4}k_{3}A^{3})^{2}}{2R} \right\} = 10 \log \left[ \frac{(A^{2})}{2R} \right]^{3} + 10 \log \left[ [2R]^{2} (\frac{3}{4}k_{3})^{2} \right]$$

$$= 3 \times 10 \log \left[ \frac{(A^{2})}{2R} \right] + 10 \log \left( \frac{9}{4} (Rk_{3})^{2} \right) = 3P_{i} + \underbrace{10 \log \left( \frac{9}{4} (Rk_{3})^{2} \right)}_{\mathbf{a \ constant}}$$


$$= > P_{(2\omega_{1}-\omega_{2})} : P_{i} \ line \quad \underline{\text{slope 3:1}}$$

- $\Rightarrow$  <u>3rd-order intercept point</u> (IP3) is the *intersection point* of  $P_o: P_i$  line &  $P_{(2\omega_1-\omega_2)}: P_i$  line
  - Output power at IP3 (OIP3) : P<sub>IP3</sub>
  - Input power at IP3 (IIP3) :  $P_{i(IP3)}$

#### 4. Nonlinear Distortion in RF/Microwave Systems

#### Nonlinear Distortion - Inter-modulation Distortion (IMD)


**3rd order intercept point : IP3 Input IP** is the point where the output power at  $\omega_1$  equals to output power at  $(2\omega_1 - \omega_2)$ 



# 4. Nonlinear Distortion in RF/Microwave Systems

#### Nonlinear Distortion — Inter-modulation Distortion (IMD)

**3rd order intercept point : IP3 Input IP** is the point where the output power at  $\omega_1$  equals to output power at  $(2\omega_1 - \omega_2)$ 



For a given input level (well below  $P_{IdB}$ ), the IIP<sub>3</sub> can be calculated by halving the difference between the output fundamental and IM levels and adding the result to the input level, where all values are expressed as logarithmic quantities.

2021 FEEE - HCMUT

67


dio Communication Circuits

021 FEEE - HCMUT

Radio Communication Circu

#### 4. Nonlinear Distortion in RF/Microwave Systems

# Nonlinear Distortion - Inter-modulation Distortion (IMD)



### 4. Nonlinear Distortion in RF/Microwave Systems

## Example of Third Intercept Point

A low-noise amplifier senses a -80-dBm signal at 2.410 GHz and two -20-dBm interferers at 2.420 GHz and 2.430 GHz. What IIP $_3$  is required if the IM products must remain 20 dB below the signal? For simplicity, assume 50- $\Omega$  interfaces at the input and output.

Solution:

2021 FEEE - HCMU

69

Radio Communication Circuits

© 2021 FEEE - HCMU

70

Radio Communication Circuit

#### 4. Nonlinear Distortion in RF/Microwave Systems

#### Nonlinear Distortion - SFDR)

# Spurious Free Dynamic Range SFDR

- 1. Dynamic Range (DR): Ratio of the maximum input level that the circuit can tolerate to the minimum input level at which the circuit provides reasonable signal quality.
- 2. Upper-end of the dynamic range (DR) depends on the intermodulation behavior
- 3. The lower end depends on sensitivity and NF


 $G_1$ 

 $\frac{1}{IIP_3} = \frac{1}{IIP_{3,1}} + \frac{G_1}{IIP_{3,2}} + \frac{G_1 \cdot G_2}{IIP_{3,3}} + \dots$ 

IIP<sub>3</sub>: Power quantity G: Power gain

© 2021 EFFE. HCMIT 74 Padio Communication Circuits © 2021 EFFE. HCMIT 79 Padio Communication Circuits

# **Nonlinear Distortion** – SFDR)



# **Nonlinear Distortion – SFDR)**

# Spurious Free Dynamic Range SFDR

$$SFDR = P_{in,\max} - P_{in,\min} = P_{in,\max} - (-174 + 10\log B + SNR_{out,\min} + NF)$$

$$P_{in,\max} = \text{maximum input level in a two-tone test, where IM3} \le \text{noise floor}$$

$$SFDR = \frac{2(IIP_3 - F)}{3} - SNR_{out,min}$$

Prove?

© 2021 FEEE - HCMUT 73 Radio Communication Circuits © 2021 FEEE - HCMUT 74