


Lesson 1 Infrared Sensor Assembly







Please connect the infrared sensor to IO23 IO22 port on controller with 20cm 4Pin cable, as shown in the figure below.

