

- [AR RF Master Interlock PLC HMI Manual](#)
 - [Definitions/Abbreviations](#)
 - [Audience](#)
 - [Remote connection to the MI HMI](#)
 - [Main Menu](#)
 - [Configuration Menu](#)
 - [Calibration Menu](#)
 - [High-level Displays](#)
 - [External subsystems](#)
 - [Detail Displays Menu](#)

AR RF Master Interlock PLC HMI Manual

This manual describes contents of the AR RF Master Interlock PLC HMI

Definitions/Abbreviations

Term	Definition
MI HMI	AR RF Master Interlock PLC HMI

Audience

This manual is intended to be useful for:

- Control System Engineers
- RF Engineers
- Operators

Remote connection to the MI HMI

See [Remote Connection to AR RF Master Interlock PLC HMI](#) to have read-only access to the HMI screens

Main Menu

The Main Menu provides navigation to all screens of the MI HMI. This screen contains several sub menu which further navigate to individual screens

Configuration Menu

Calibration Menu

High-level Displays

External subsystems

Detail Displays Menu