HOW TO IMPORT KEYS TO SPSDK/SPT

NXP SE FEB.2025




SECURE CONNECTIONS FOR A SMARTER WORLD


PUBLIC

IXP, THE NXP LOGO AND NXP SECURE CONNECTIONS FOR A SMARTER WORLD ARE TRADEMARKS OF NXP B.V.





THE KEYS HAVE BEEN GENERATED BY KW45_FW_SCRIPTS_20220804





GENERATE PUBLIC KEYS AND RENAME THE KEYS









SPSDK

- Copy keys from KW45_FW_Scripts_20220804 to SPSDK workspace/keys
- 2. Run 1.generate_keys.cmd to generate cert-blocks




CREATE MCUXPRESSO SECURE PROVISIONING TOOL PROJECT






GENERATE KEYS




DELETE THE KEYS GENERATED BY SPT AND COPY KEYS FROM KW45_FW_SCRIPTS_20220804 TO SPT WORKSPACE




GENERATE CERT BLOCK



GENERATE DC



GENERATE DC



GENERATE DC

