# **Chapter7 Serial Devices**


## Common serial device

- > Printer
- > Terminal
- > Modem

## Serial standard (1)

#### > RS-232 standard on DB25 connector

- Electrical characteristics
- Meaning of each signal wire
- Ping assignment
- DB25P (male)
- DB25S (female)





## Serial standard (2)


## > RS-232 signals and ping assignment


Pin	Name	Function	Pin	Name	Function
1	FG	Frame ground	14	STD	Secondary TD
2	TD	Transmitted data	15	TC	Transmit clock
3	RD	Received data	16	SRD	Secondary RD
4	RTS	Request to send	17	RC	Receive clock
5	CTS	Clear to send	18	×	Not assigned
6	DSR	Data set ready	19	SRTS	Secondary RTS
7	SG	Signal ground	20	DTR	Data terminal ready
8	DCD	Data carrier detect	21	SQ	Signal quality detector
9		Positive voltage	22	RI	Ring indicator
10	-	Negative voltage	23	DRS	Data rate selector
11	=	Not assigned	24	SCTE	Clock transmit externa
12	SDCD	Secondary DCD	25	BUSY	Busy
13	SCTS	Secondary CTS			

## Serial standard (3)

#### > Alternative connectors

- Since RS-232 is overkill for all real-world situation
  - Mini DIN-8
  - DB-9
  - RJ-45





## Serial standard (4)

## > Cable Length

- RS-232 specifies a maximum length of 75 feet at 9600 bps
  - 75 \* 30.5 ≒ 22 m
- In reality, they hit the limit between  $800 \sim 1000$  feet

#### **Serial Device File**

- Serial ports are represented by device files under /dev
- > The name of the device file is no big deal
  - behavior is determined by the major and minor device number

System	Device files for the first two serial ports
FreeBSD	/dev/ttyd[0,1] (com1, com2)
Red Hat	/dev/ttyS[0,1]
Solaris	/dev/term[a,b]
SunOS	/dev/tty[a,b]

```
tytsai@tybsd:/dev> ls -al | grep ttyd
crw------ 1 root wheel 28, 0 Sep 19 20:14 ttyd0
crw----- 1 root wheel 28, 1 Sep 19 20:14 ttyd1
crw----- 1 root wheel 28, 2 Sep 19 20:14 ttyd2
crw----- 1 root wheel 28, 3 Sep 19 20:14 ttyd3
```

## **Kernel Configuration**

### > dmesg

– /sbin/dmesg | grep sio

```
sio0 at port 0x3f8-0x3ff irq 4 flags 0x10 on isa0 sio0: type 16550A sio1 at port 0x2f8-0x2ff irq 3 on isa0 sio1: type 16550A
```

## > Kernel configuration file

- device sio0 at isa? port IO COM1 irq 4
- device sio1 at isa? port IO\_COM2 irq 3

## **Software Configuration**

- > Depend on the type of serial device
  - Hardwired terminal
  - Modem
  - Printer
    - Left to chapter23

# Configuration of Hardwired Terminals (1)


#### > Two main tasks

- Make sure each process is attached to a terminal to accept logins
- Make sure that information about the terminal is available once a user login

# Configuration of Hardwired Terminals (2)

#### > The login process

- init spawn getty according to /etc/ttys
- getty sets the port's initial characteristics and print the prompt
- User enter login name
- getty executes login program
- login request password
- login prints /etc/motd
- login sets up environment variables
- login runs a shell for user



# Configuration of Hardwired Terminals (3)

- > Terminal Configuration Files
  - On/Off
    - whether the terminal should be run a getty
  - term type
    - Virtual, network, dial-in
  - Parameter
    - Terminal parameters, such as speed

System	On/Off	Term Type	Parameters	Monitor
FreeBSD	/etc/ttys	/etc/ttys	/etc/gettytab	getty
Red Hat	/etc/inittab	/etc/ttytype	/etc/gettydefs	getty
SunOS	/etc/ttytab	/etc/ttytab	/etc/gettytab	getty
Solaris	_sactab	_sactab	zsmon/_pmtab	ttymon

# **Configuration of Hardwired Terminals (4)**

- > FreeBSD: /etc/ttys
  - Format

    device program termtype {on|off} [secure]
  - Restart init process
    - kill -1 1
    - kill -HUP 1

ttyv1	"/usr/libexec/getty Pc"	cons25	on	secure
ttyv2	"/usr/libexec/getty Pc"	cons25	on	secure
ttyd0	"/usr/libexec/getty std.9600"	dialup	off	secure
ttyd1	"/usr/libexec/getty std.9600"	dialup	off	secure
ttyp0	none	network		
ttyp1	none	network		

# Configuration of Hardwired Terminals (5)

- > FreeBSD: /etc/gettytab
  - Associate symbolic names with port configuration information, such as speed, parity, prompt
  - man gettytab

## **Special Characters and The terminal driver**

> The terminal driver supports several special function when typing special keys

Name	Default	Function	
Erase	^H	Erases one character of input	
WErase	^W	Erases one word of input	
Kill	^U	Erases the entire line of input	
EOF	^D	Sends an "end of file" indication	
INTR	^C	Interrupts the currently running process	
Quit	^\	Kills the current process with a core dump	
Stop	^S	Stops output to the screen	
Start	^Q	Restarts output to the screen	
Discard	^0	Throws away pending output	
Suspend	^Z	Suspends the current process	
LNext	^V	Interprets the next character literally 1	

## stty – Set Terminal Options

- Change and query various settings of the terminal drivers
  - There are about a zillion options
  - man tty(4) and stty(1)
- > Example
  - stty intr "^C" kill "^U" erase "^H"
  - stty –a
  - reset tty
    - reset
    - stty sane

```
speed 38400 baud; 24 rows; 80 columns;
lflags: icanon isig iexten echo echoe -echok echoke -echonl echoctl
    -echoprt -altwerase -noflsh -tostop -flusho pendin -nokerninfo
    -extproc
iflags: -istrip icrnl -inlcr -igncr ixon -ixoff ixany imaxbel -ignbrk
    brkint -inpck -ignpar -parmrk
oflags: opost onlcr -ocrnl -oxtabs -onocr -onlret
cflags: cread cs8 -parenb -parodd hupcl -clocal -cstopb -crtscts -dsrflow
    -dtrflow -mdmbuf
cchars: discard = ^O; dsusp = ^Y; eof = ^D; eol = <undef>;
    eol2 = <undef>; erase = ^?; erase2 = ^H; intr = ^C; kill = ^U;
    lnext = ^V; min = 1; quit = ^\; reprint = ^R; start = ^Q;
    status = ^T; stop = ^S; susp = ^Z; time = 0; werase = ^W;
```


## Other Common I/O ports (1)

### > Parallel ports

- Similar to serial ports in concept, but parallel ports transfer 8 bits of data at once
- IEEE-1284 standard
- Male DB25 ← → male Centronics connector
- Parallel device is rarely supported under UNIX



Female Centronics connector



Male Centronics connector

## Other Common I/O ports (2)

#### > USB - Universal Serial Bus

- Up to 127 devices can be connected
- Standardized connectors
- Devices can be connected and disconnected without powering down
- Up to 12Mb/s
- > USB 2.0
  - Up to 480Mb/s