

INTERIOR TRIM AND ORNAMENTATION

C-PILLAR TRIM PANEL (G1904987)

REMOVAL AND INSTALLATION

|          |                                 |                    |      |              |  |
|----------|---------------------------------|--------------------|------|--------------|--|
| 76.13.83 | C - POST<br>TRIM PAD -<br>RENEW | ALL<br>DERIVATIVES | 0.50 | USED WITHINS |  |
|----------|---------------------------------|--------------------|------|--------------|--|


REMOVAL




NOTE:

Removal steps in this procedure may contain installation details.


1.



2.





3.




*Torque:* **5.4 Nm**

⚠ CAUTION:

Take extra care not to damage the wiring harnesses.




6.



7.

### NOTE:

Do not disassemble further if the component is removed for access only.



*Torque: 2.5 Nm*

## INSTALLATION

1.

To install, reverse the removal procedure.

