

INTERIOR TRIM AND ORNAMENTATION

COWL SIDE TRIM PANEL (G1823072)

REMOVAL AND INSTALLATION

76.13.30	A-POST LOWER TRIM PAD - RENEW	ALL DERIVATIVES	0.10	USED WITHINS	
----------	--	--------------------	------	--------------	--

REMOVAL




NOTES:

- Some variation in the illustrations may occur, but the essential information is always correct.
- Some components shown removed for clarity.
- Removal steps in this procedure may contain installation details.
- Left side shown, right side similar.


1.

Refer to: Front Scuff Plate Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).


2.



3.




4.



Torque: 3.5 Nm

5.



Torque: 2.5 Nm

INSTALLATION

1.

To install, reverse the removal procedure.