

FRONT END BODY PANELS

FENDER (G1823028)

REMOVAL AND INSTALLATION

REMOVAL



CAUTION:

Always protect paintwork and glass when removing exterior components.



NOTE:

Removal steps in this procedure may contain installation details.

1.

Refer to: Battery Disconnect and Connect (414-01 Battery, Mounting and Cables, General Procedures).

2.

Refer to: Fender Splash Shield (501-02 Front End Body Panels, Removal and Installation).


3.

Refer to: Headlamp Assembly (417-01 Exterior Lighting, Removal and Installation).


4.

Refer to: Front Door (501-03, Removal and Installation).



5.



6.




7.



E173932


8.



E173804


Torque: 10 Nm

9.




Torque: 10 Nm

10.



Torque: 10 Nm


11.



E173807

Torque: 10 Nm

12.



E173809

INSTALLATION

1.

To install, reverse the removal procedure.