

EXTERIOR TRIM AND ORNAMENTATION

RADIATOR GRILLE (G1914956)

REMOVAL AND INSTALLATION

76.55.03	RADIATOR GRILLE - RENEW	ALL DERIVATIVES	1.50	USED WITHINS	
----------	-------------------------	-----------------	------	--------------	--

REMOVAL



NOTES:

- Some variation in the illustrations may occur, but the essential information is always correct.
- Some components shown removed for clarity.
- Removal steps in this procedure may contain installation details.

1.

Refer to: Startup Battery Disconnect and Connect (414-01, General Procedures).

2.



WARNING:


Make sure to support the vehicle with axle stands.

Raise and support the vehicle.


3.

Refer to: Front Bumper (501-19, Removal and Installation).

4.



5.



Torque: 2.5 Nm


**CAUTIONS:**

- Protect the surrounding paintwork to avoid damage.
- Take extra care not to damage the clips.



△ NOTE:


Do not disassemble further if the component is removed for access only.



Torque: **2.5 Nm**

⚠ CAUTION:

Make sure that the component is correctly located on the locating dowels.

**INSTALLATION**

1.

To install, reverse the removal procedure.