

FRONT END BODY PANELS

FRONT CROSSMEMBER (G1888175)

REMOVAL AND INSTALLATION

REMOVAL

NOTE:

Removal steps in this procedure may contain installation details.


1.

Refer to: Headlamp Assembly (417-01 Exterior Lighting, Removal and Installation).


2.



3.




4.




Torque: **10.5 Nm**

5.



6.



Torque: 25 Nm

INSTALLATION

1.

To install, reverse the removal procedure.