

INTERIOR TRIM AND ORNAMENTATION

REAR SCUFF PLATE TRIM PANEL (G1904990)

REMOVAL AND INSTALLATION

|          |                                               |                    |      |              |  |
|----------|-----------------------------------------------|--------------------|------|--------------|--|
| 76.13.82 | ROCKER<br>PANEL REAR<br>INNER TRIM<br>- RENEW | ALL<br>DERIVATIVES | 0.10 | USED WITHINS |  |
|----------|-----------------------------------------------|--------------------|------|--------------|--|

REMOVAL



CAUTION:

LH illustration shown, RH is similar.




NOTE:

Removal steps in this procedure may contain installation details.

1.

**NOTE:**


Do not remove the component at this stage.




2.

**CAUTION:**

Take extra care not to damage the wiring harness clips.



3.



## INSTALLATION

1.

To install, reverse the removal procedure.