

FRONT END BODY PANELS

SECONDARY BULKHEAD RIGHT PANEL - INGENIUM I4 2.0L DIESEL

(G1817281)

REMOVAL AND INSTALLATION

76.11.30	ENGINE COMPARTMENT RIGHT HAND COVER - RENEW	2000 CC, INGENIUM DIESEL	0.70	USED WITHINS	
----------	---	--------------------------------	------	--------------	--

REMOVAL



NOTE:

Removal steps in this procedure may contain installation details.

1.

Disconnect the battery ground cable.
Refer to: Startup Battery Disconnect and Connect (414-01, General Procedures).


2.

Refer to: Engine Cover - INGENIUM I4 2.0L Diesel (501-05, Removal and Installation).

3.


Refer to: Cowl Vent Screen (501-02, Removal and Installation).

4.




Torque: 55 Nm

5.




 NOTE:

LHD vehicles.



Torque: 8 Nm



Torque: 10 Nm

1.

To install, reverse the removal procedure.