

INFORMATION AND ENTERTAINMENT SYSTEM - VEHICLES WITH: INCONTROL TOUCH TOUCHSCREEN (G2131957)

REMOVAL AND INSTALLATION

86.50.39	MULTI FUNCTION TOUCH SCREEN DISPLAY MODULE - RENEW	ALL DERIVATIVES	0.30	USED WITHINS	
87.01.14	TOUCH SCREEN (TS) - RENEW	ALL DERIVATIVES	0.30	USED WITHINS	
87.02.14	TOUCH SCREEN (TS) - RENEW	ALL DERIVATIVES	0.30	USED WITHINS	

REMOVAL

1.

Disconnect the startup battery ground cable.


Refer to: Startup Battery Disconnect and Connect (414-01, General Procedures).

2.

Remove the integrated control panel.


Refer to: Integrated Control Panel (415-01B, Removal and Installation).

3.



Remove the touch screen switchpack trim panel.

4.



Remove the touch screen.

1.

Install the touch screen.

Torque: **3.5 Nm**

2.

Install the touch screen switchpack trim panel.

Torque: **3.5 Nm**

3.

Install the integrated control panel.

Refer to: Integrated Control Panel (415-01B, Removal and Installation).

4.

Connect the startup battery ground cable.

Refer to: Startup Battery Disconnect and Connect (414-01, General Procedures).