

A

- About this handbook.....2
- Accessories.....142
- Active differential control.....86
- Active exhaust.....75
- Adaptive dynamics.....87
- Adaptive front lighting system.....44
 - warning lamp.....39
- Adaptive headlamps.....44
- After a collision
 - pedestrian protection system.....197
- Age degradation (tyres).....181
- Airbags
 - cover cleaning.....152
 - curtain.....32
 - deployment.....31, 33
 - disability modifications.....34
 - disabling.....33
 - front.....32
 - locations.....31
 - maintenance.....142
 - service information.....34
 - side.....32
 - warning lamp.....33, 40
- Air conditioning
 - automatic recirculation.....63
 - driver controls.....
 - front.....62
- Air quality sensor.....63
- Alarm.....17, 142
 - automatic relocking and arming.....18
 - battery backed sounder.....17
 - deactivating.....17
 - passive arming.....17
 - perimeter.....17
 - security sensor fault.....18
 - tilt sensor.....17
- Anchor points (luggage).....68
- Anti-lock braking system (ABS) warning
 - lamp.....39
- Anti-theft system.....142
- Anti-trap protection
 - windows.....58
- Approach lamps.....44
- Audible warnings.....42
- Audio
 - automatic station retune.....103
 - CD loading.....98
 - changing portable media device.....111
 - connecting portable media devices.....109
 - DAB radio
 - controls.....104
 - settings.....105
 - stations.....106
 - DVD player controls.....115
 - full screen view.....116
 - licensing.....99, 101
 - portable media connections.....108
 - portable media controls.....107
 - portable media pairing.....110–111
 - portable media playing.....110
 - radio controls.....102
 - sound settings.....98
 - touch screen controls.....97
 - TV controls.....113
 - video player controls.....115
- Auto lamps
 - wiper detection.....44
- Automatic locking.....9, 18
- Automatic recirculation.....63
- Automatic speed limiter
 - warning lamp.....40
- Automatic transmission.....78
 - gear shift warning lamp.....41
 - shift paddles.....79
 - temporary manual selection.....79
- Auto zoom (navigation).....126
- Auxiliary device connection.....110

B

- Battery
 - boost starting.....162
 - care.....159
 - charging.....162
 - connecting jump leads.....160
 - disconnecting jump leads.....162
 - maintenance.....159

monitoring system.....	160
replacing.....	162
using a starting aid.....	162
warning symbols.....	159
Battery backed sounder.....	17
Blind spot monitor	
closing vehicle sensing.....	53
displayed messages.....	54
notification of overtaking vehicle.....	52
sensor blockage.....	54
Bluetooth	
compatibility.....	118
pairing	
via the phone.....	119
portable media	
pairing.....	110–111
playing.....	110
telephone.....	118
icons.....	120
overview.....	117
pairing.....	119
phonebook.....	121
safety.....	118
Bonnet	
closing.....	145
opening.....	144
Booster seats for larger children.....	30
Boost starting.....	162
Brakes	
ABS warning lamp.....	39
brake pads.....	143
electronic brake force distribution.....	88
emergency brake assist.....	88
fluid check.....	156
fluid specification.....	156
fluid top up.....	156
handbrake.....	89
important information.....	88
parking brake warning lamp.....	39
pedal travel.....	206
warning lamp (red).....	38
warning lamp (yellow).....	39
Bulbs	
changing a bulb.....	146

rear fog lamp.....	147
reverse lamps.....	148
specification.....	205

C

Call volume.....	121
Cameras	
rear camera.....	91, 94
reverse traffic detection.....	93
Capacities.....	205
Carpets and mats.....	152
Car-wash.....	150
CD player	
CD loading.....	98
portable media pairing.....	110–111
portable media playing.....	110
Change a connected phone.....	120
Changing a bulb.....	146
Changing a fuse.....	164
Changing a wheel	
locking wheel nuts.....	192
recommended process.....	191
safety warnings.....	190
Charging the vehicle battery.....	162
Chassis number.....	199
Child safety	
booster seats.....	30
check list.....	29
child seats.....	28
larger children.....	30
positioning.....	30
recommended child seats.....	30
Cleaning	
airbag covers.....	152
alloy wheels.....	150
automatic car wash.....	150
carpets and mats.....	152
exterior.....	150
paintwork.....	150
glass.....	151
interior.....	151–152
leather.....	151
parking sensors.....	91
polishing.....	151

rear screen.....	151	Dealer locations.....	131
removing grease.....	151	Declarations of conformity.....	209
removing stains.....	152	navigation system.....	136
removing tar.....	151	Deselecting valet mode.....	61
seat belts.....	152	Destination entry.....	127
using a car-wash.....	150	postcode.....	130
washer jets.....	146	search area.....	127
Climate control		Diesel	
automatic recirculation.....	63	filler flap.....	139
driver controls.....		specification.....	139
front.....	62	Differential control.....	86
heated seats.....	63	Dimensions.....	203
Clock.....	35	Direction indicators.....	43
Closing the bonnet.....	145	warning lamp.....	41
Closing vehicle sensing.....	53	Door mirrors.....	50
Compact disc.....	98	blind spot monitor.....	52
Condensation (headlamps).....	45	closing vehicle sensing.....	53
Conformity declarations.....	136, 209	sensors.....	54
Connecting jump leads.....	160	Door transceiver	
Controls		assistance.....	57
driving position.....		erase all programming.....	56
overview.....		garage door opener.....	55
Convertible roof		programming.....	55
closing.....	69	programming a single button.....	56
manual re-set.....	70	programming the garage door opener.....	55
opening.....	69	rolling code device programming.....	56
Coolant		Double locking.....	16
checking the level.....	155	full alarm.....	17
specification.....	155	Drive away locking.....	9
top up.....	155	Drive control	
Covers		operation.....	82
refitting.....	146	Driver controls.....	
removal.....	145	Driving	
Critical warning messages.....	38	activating intelligent stop/start.....	76
Cruise control.....	96	active exhaust.....	75
warning lamp.....	41	after a collision.....	197
D		automatic speed limiter.....	95
DAB radio		before starting.....	197
ensembles.....	106	blind spot monitor.....	52
settings.....	105	closing vehicle sensing.....	53
DAB radio controls.....	104	blind spot monitor messages.....	54
Data recording.....	197–198	brakes important information.....	88
Daytime running lamps.....	44	daily checks.....	143
		deactivating intelligent stop/start.....	76

driver controls.....	40	Electronic brake force distribution.....	88
DSC active warning lamp.....	40	Electronic data.....	198
DSC configurable modes.....	84	Emergency (navigation).....	130
DSC dynamic launch.....	83	Emergency brake assist.....	88
DSC rain/ice/snow mode.....	82	Emergency key locking.....	18
electronic brake force distribution.....	88	Emergency release luggage compartment.....	67
emergency brake assist.....	88	Engine	
gear shift warning lamp.....	41	antifreeze level.....	155
rain sensor.....	48	compartment opening.....	144
running-in.....	142	coolant level.....	155
sitting correctly.....	22	oil level.....	153
using cruise control.....	96	running-in.....	142
weekly checks.....	143	specifications.....	200
Driving abroad		starting	
beam pattern.....	45	keyless start backup.....	74
headlamps.....	45	switching off.....	73
Driving position memory.....	21	Engine/transmission warning lamp.....	40
recalling a position.....	22	Engine block heaters	
Dynamic launch		antifreeze.....	75
DSC.....	83	cold starting.....	75
Dynamic stability control (DSC).....	81–82	connecting to mains supply.....	75
configurable.....	84	Engine compartment	
DSC active warning lamp.....	40	fluid filler locations.....	153
DSC off warning lamp.....	40	Engine covers	
dynamic launch.....	83	refitting.....	146
rain/ice/snow mode.....	82	removal.....	145
spoiler.....	85	Engine starting.....	73
switching between DSC and tracDSC.....	82	active exhaust.....	75
switching off.....	81	failure to start.....	74
switching on.....	81	Engine temperature warning lamp.....	38
E		Entering a destination.....	127
Easy route.....	128	Entering the vehicle	
Electric parking brake.....	89	entry and exit mode.....	23
Electric roof		global opening.....	9
closing.....	69	keyless entry.....	8
manual re-set.....	70	luggage compartment.....	10
opening.....	69	tailgate operation.....	10
Electric seats.....	19	unlocking mode.....	8
position memory.....	21	Ethanol.....	137
recalling a memory position.....	22	EU conformity (navigation system).....	136
restricted seat travel.....	22	Event data recording.....	198
Electric windows		Exiting the vehicle	
operation.....	58	arming the alarm.....	15, 18

closing mislock.....	16
door locks and release levers.....	16
double locking.....	16
emergency locking.....	18
full alarm.....	17
global closing.....	16
interior locks.....	16
passive arming.....	17
perimeter alarm.....	17
single locking.....	16
Exterior cleaning.....	150
Exterior lamps	
bulb changing.....	146
bulb specification.....	205
Exterior mirrors	
electric.....	50
manual.....	50
mirror dip when reversing.....	51
External temperature	
warning lamp.....	40
Extinguisher.....	149
Extra features.....	61

F

Favourite locations	
navigation.....	129
navigation details.....	129
Fire extinguisher.....	149
First aid kit.....	149
Flat spots.....	181
Fluids	
brake	
check.....	156
specification.....	156
top up.....	156
capacities.....	205
coolant	
specification.....	155
top up.....	155
engine oil check.....	153
filler locations.....	153
oil	
top up.....	154
power steering	
specification.....	157
power steering check.....	157
specifications.....	201
washer fluid.....	158
check.....	158
specification.....	158
Fog lamps	
warning lamps	
rear.....	40
Front airbags.....	32
Front climate control.....	62
automatic recirculation.....	63
Front parking aids.....	90
system fault.....	91
volume.....	91
Front wipers.....	48
Fuel and refuelling.....	139
consumption.....	140
ethanol.....	137
filler flap.....	139
fuel filler flap.....	138
fuel specification.....	139
methanol.....	137
methyl tertiary butyl ether (MTBE).....	138
octane rating.....	137
running out.....	138
safety precautions.....	137
tank capacity.....	139
Fuel consumption.....	140
combined cycles.....	141
extra-urban cycle.....	140
urban cycle.....	140
Fuel filler flap.....	138
Fuel gauge.....	35
Fuel system.....	144
Full screen view for video.....	116
Fuses	
changing.....	164
engine compartment fuse box.....	165
locations.....	163
luggage compartment fuse box.....	174
passenger compartment fuse box.....	168

G

Garage door opener.....	55
assistance.....	57
entry gate.....	57
erase all programming.....	56
programming.....	55
programming a rolling code device.....	56
programming a single button.....	56
Gearbox.....	
automatic.....	78
driver controls.....	
emergency park release.....	195
gear shift warning lamp.....	41
limp home mode.....	80
operation.....	82
Glass cleaning.....	151
Global closing.....	16
Global opening.....	9

H

Handbook symbols.....	2
Handbrake.....	89
Headlamps.....	43
adaptive.....	44
approach lamps.....	44
beam pattern.....	45
bulb changing.....	146
bulb specification.....	205
condensation.....	45
daytime running lamps.....	44
driver controls.....	
driving abroad.....	45
high beam assist.....	44
high beam assist warning lamp.....	41
high beam warning lamp.....	41
warning lamp (AFS).....	39
washers.....	49
xenon.....	146
Heated seats.....	63
Heated steering wheel.....	23
Heating and ventilation.....	62
automatic recirculation.....	63
driver controls.....	

front.....	62
heated seats.....	63
High beam assist.....	44
Home (navigation).....	130
Homelink.....	55
assistance.....	57
erase all programming.....	56
gate/door opener.....	57
programming.....	55
programming a single button.....	56
programming the garage door opener.....	55
rolling code device programming.....	56

I

Ignition.....	
rolling re-start.....	73
switching on.....	73
Indicators warning lamp.....	41
Information messages.....	38
Infotainment.....	
automatic station retune.....	103
CD loading.....	98
DAB radio.....	
settings.....	105
stations.....	106
DAB radio controls.....	104
full screen view.....	116
media player controls.....	115
portable media.....	
changing.....	111
connecting devices.....	109
connecting multiple devices.....	110
connections.....	108
controls.....	107
pairing.....	110–111
playing.....	110
radio controls.....	102
sound settings.....	98
touch screen.....	
audio/video controls.....	97
care.....	60
extra features.....	61
home menu.....	59
operating.....	60

settings.....	60
setup.....	60
TV controls.....	113
Instrument panel.....	35, 152
display units.....	37
fuel range.....	37
lamp test.....	38
menu.....	35
driving features.....	35
instrument display.....	35
trip computer.....	35
vehicle set-up.....	35
service indicator.....	37
warning lamps.....	38
warning messages.....	36
Intelligent stop/start	
activating.....	76
deactivating.....	76
Intelligent stop/start warning lamp.....	41
Interior cleaning.....	151–152
airbag covers.....	152
carpets and mats.....	152
Interior lamps.....	46
ambient lighting.....	46
bulb changing.....	146
bulb specification.....	205
intensity.....	46
types.....	46
Interior locking.....	16
Introduction	
instructional videos.....	3

J

Jump starting	
connecting a starting aid.....	162
connecting jump leads.....	160
disconnecting jump leads.....	162

K

Keyless entry.....	8
--------------------	---

L

Label locations.....	199
----------------------	-----

Lamps.....	43
auto lamps wiper detection.....	44
bulb changing.....	146
bulb specification.....	205
condensation.....	45
test.....	38
TPMS warning lamp.....	40
warning lamps.....	38
xenon headlamps.....	146
Leather cleaning.....	151
Licensing	
audio/video.....	99, 101
Lighting	
ambient lighting.....	46
interior lamps intensity.....	46
interior lamps locations.....	46
Limp home mode.....	80
Load carrying	
cover.....	67
Load securing.....	68
Loadspace	
emergency release.....	67
Loadspace cover.....	67
Locking	
automatic relocking.....	18
door locks and release levers.....	16
double locking.....	15–16
drive away.....	9
emergency locking.....	18
global closing.....	16
in an emergency.....	18
mislock.....	16
security sensor fault.....	18
single.....	16
single locking.....	15
with the emergency key.....	18
Locking wheel nuts.....	192
Lubricants specifications.....	201
Luggage compartment	
anchor points.....	68
cover.....	67
emergency release.....	67

M

Maintenance

brake fluid level.....	156
brake pads.....	143
bulb changing.....	146
bulb specification.....	205
capacities.....	205
changing a fuse.....	164
checking tyre pressure after a repair.....	188
cleaning	
alloy wheels.....	150
exterior.....	150
glass.....	151
interior.....	151–152
leather.....	151
parking sensors.....	91
rear screen.....	151
seat belts.....	152
closing the bonnet.....	145
daily checks.....	143
disconnecting jump leads.....	162
engine compartment fuse box.....	165
engine coolant level.....	155
engine oil level.....	153
fuel system.....	144
fuse box (passenger compartment).....	168
jump starting.....	162
label locations.....	199
lubricants and fluid specifications.....	201
luggage compartment fuse box.....	174
oil top up.....	154
paintwork repair.....	150
polishing.....	151
power steering fluid level.....	157
removing grease and tar.....	151
removing stains.....	152
running-in.....	142
smart key battery.....	13
tyre repair kit.....	186
tyre repair procedure.....	187
using a starting aid.....	162
washer fluid level.....	158
washer jets.....	146

weekly checks.....	143
wheel balancing.....	143
Manual seats.....	21
Map.....	130
auto zoom.....	126
split screen.....	126
Message centre display units.....	37
Methanol.....	137
Minor paintwork repairs.....	150
Mirrors	
blind spot monitor.....	52
closing vehicle sensing.....	53
sensors.....	54
dip when reversing.....	51
driver controls.....	
exterior mirrors.....	50
Motorway	
destination entry.....	130
Mpg.....	140

N

Navigation

Arabic language.....	132
automatic route learning.....	128
avoid points.....	128
destination entry.....	127
search area.....	127
destination entry by postcode.....	130
easy route.....	128
emergency contacts.....	130
favourite locations.....	129
home location.....	130
legals.....	134–136
licence terms.....	134–135
licensing.....	134–136
map.....	130
auto zoom.....	126
split screen.....	126
menu.....	124
motorway selection.....	130
operating.....	122
overview.....	122
points of interest (POI).....	131–132
categories/sub-categories.....	131

search.....	131
previous destinations.....	130
quick POI selection.....	129
restore defaults.....	129
screen modes.....	127
start guidance.....	128
TMC.....	132, 134
icons.....	133
voice guidance.....	129
warranty disclaimer.....	136

O

Occupant safety	
cleaning seat belts.....	152
recommended child seats.....	30
seat belt pre-tensioners.....	26
seat belt reminder warning.....	26
seat belt safety.....	25
seat belts warning lamp.....	39
using seat belts.....	24
Octane rating.....	137
Oil	
engine oil specification.....	154
filler locations.....	153
specification.....	201
top up.....	154
used engine oil.....	144
Opening the bonnet.....	144
Oversteer.....	81
Overview	
driver controls.....	
Owner maintenance.....	143

P

Paddle shift.....	79
Paintwork	
cleaning.....	150
repair.....	150
Pairing	
via the phone.....	119
Pairing a phone.....	119
Parking aids	
cleaning the sensors.....	91

operating.....	90
rear camera.....	91, 94
reverse traffic detection.....	93
system fault.....	91
volume.....	91
Parking brake.....	89
warning lamp.....	39
Park position emergency release.....	195
Parts.....	142
Passenger compartment fuse box.....	168
Passive alarm arming.....	17
Pedestrian protection system.....	197
after deployment.....	197
Perimeter alarm.....	17
Petrol	
specification.....	139
Petrol consumption.....	140
Petrol filler flap.....	139
Phone	
Bluetooth compatibility.....	118
call volume.....	121
change the phone.....	120
icons.....	120
overview.....	117
pairing via the phone.....	119
pairing via the touch screen.....	119
phonebook.....	121
safety.....	118
steering wheel controls.....	120
Points of interest (POI).....	131
my POI.....	132
search.....	131
Polishing the bodywork.....	151
Portable media	
changing device.....	111
connecting devices.....	109
connecting multiple devices.....	110
connections.....	108
controls.....	107
pairing.....	110–111
playing.....	110
Postcode	
destination entry.....	130
Powered tailgate.....	12

Power steering	
fluid	
specification.....	157
fluid level.....	157
Pressure checking (tyres)	
checking after a repair.....	188
Pressures	
tyres.....	177
Previous destination.....	130
Punctured tyres.....	180
Puncture repair kit.....	186
instructions for use.....	187
repair procedure.....	187
safety.....	186

Q

QR codes for smart phones	
instructional videos.....	3
Quick POI selection.....	129

R

Radio	
automatic station retune.....	103
controls.....	102
DAB	
settings.....	105
stations.....	106
DAB controls.....	104
Radio data system auto retune.....	103
Radio frequency regulations.....	208
Rain sensor.....	48
RDS	
TMC	
icons.....	133
overview.....	132
Rear camera	
parking aids.....	91
reverse traffic detection.....	93
sensors.....	94
Rear fog lamps warning lamp.....	40
Rear screen cleaning.....	151
Recalling seat memory position.....	22

Recording	
event data.....	198
service data.....	197
Recovery	
towing eyes.....	194
transmission park release.....	195
transporting.....	195
Refuelling	
ethanol.....	137
fuel filler flap.....	138
methanol.....	137
MTBE.....	138
octane rating.....	137
running out of fuel.....	138
safety precautions.....	137
Reminder (seat belt).....	26
Remote control	
care.....	13
driving position memory.....	21
single locking.....	16
smart key battery.....	13
system transmitters.....	206
Removing stains.....	152
Repairing paintwork damage.....	150
Replacement tyres.....	180
Resetting the windows.....	148
Restarting the engine while moving.....	73
Restore navigation default settings.....	129
Restricted seat travel.....	22
Reverse lamps	
bulb changing.....	148
Reverse parking aids.....	90
rear camera.....	94
reverse traffic detection.....	93
system fault.....	91
volume.....	91
Rolling re-start.....	73
Route.....	127
favourite locations.....	129
favourites details.....	129
Running-in.....	142
Running out of fuel.....	138

S

Safety

cleaning seat belts.....	152
fuel and refuelling.....	137
seat belt pre-tensioners.....	26
seat belt reminder warning.....	26
seat belts.....	25
seat belts warning lamp.....	39
seats for larger children.....	30
sitting correctly.....	22
TPMS pressure compensation.....	181
tyre care.....	177
tyre pressures.....	177
used engine oil.....	144
using seat belts.....	24
using the telephone.....	118
warning triangle.....	148

Safety in the garage

battery precautions.....	143
electrical components.....	143
engine fans.....	143
exhaust gases.....	143
hot components.....	143
jacking.....	143

Satellite navigation

Arabic language.....	132
automatic route learning.....	128
avoid points.....	128
cancel guidance.....	129
coordinates entry.....	130
dealer locations.....	131
destination entry.....	127
search area.....	127
destination entry by postcode.....	130
easy route.....	128
emergency contacts.....	130
favourite locations.....	129
home location.....	130
legals.....	134–136
licence terms.....	134–135
licensing.....	134–136
map.....	130
auto zoom.....	126

split screen.....	126
menu.....	124
motorway selection.....	130
operating.....	122
overview.....	122
points of interest (POI).....	131–132
categories.....	131
search.....	131
previous destinations.....	130
quick POI selection.....	129
restore defaults.....	129
screen modes.....	127
start guidance.....	128
TMC.....	132, 134
icons.....	133
voice guidance.....	129
warranty disclaimer.....	136

Screen modes.....

Screen settings

screensaver.....	60
theme.....	60
time out period.....	60
volume pop-up.....	60

Screen wash

check.....	158
specification.....	201
topping up.....	158

Search area (navigation).....

Seat belts.....	24, 152
adjusting.....	24
checks.....	25
pre-tensioners.....	26
reminder warning.....	26
safety.....	25
warning lamp.....	39

Seats

child restraint check list.....	29
child seat positioning.....	30
child seats.....	28
cleaning seat belts.....	152
electric front.....	19
heated.....	63
manual front.....	21
position memory.....	21

recalling a memory position.....	22
recommended child seats.....	30
restricted seat travel.....	22
seat belts warning lamp.....	39
sitting correctly.....	22
Securing luggage.....	68
Security.....	17
alarm.....	142
tilt sensor.....	17
automatic perimeter alarm.....	17
automatic relocking and arming.....	18
battery backed sounder.....	17
closing mislock.....	16
deactivating the alarm.....	17
locking with the emergency key.....	18
perimeter alarm.....	17
single locking.....	16
Security sensors	
fault.....	18
Selecting valet mode.....	61
Sensors	
blockage (BSM).....	54
Servicing	
airbags.....	34
data recording.....	197
Set speed limit.....	95
Settings menu.....	35
display units.....	37
Side lamps warning lamp.....	41
Silencing the alarm.....	17
Sitting correctly.....	22
Smart key	
approach lamps.....	44
battery changing.....	13
care.....	13
driving position memory.....	21
single locking.....	16
transmitters.....	206
Smart phone video	
qR codes.....	3
Snow chains.....	182
Soft top roof	
closing.....	69
manual re-set.....	70
opening.....	69
Sound settings.....	98
Specifications	
brake pedal travel.....	206
dimensions.....	203
engine.....	200
ethanol.....	137
fluids.....	201
fuel.....	139
fuel tank capacity.....	139
label locations.....	199
lubricants.....	201
methanol.....	137
MTBE.....	138
weight.....	202
wheel alignment.....	206
Speed-dependent wipers.....	48
Speed limiting.....	95
Speedometer.....	35
Split screen map.....	126
Spoiler	
manual mode.....	85
SRS.....	31
airbag warning lamp.....	40
Stability control	
DSC.....	81–82
configurable.....	84
dynamic launch.....	83
rain/ice/snow mode.....	82
switching between DSC and tracDSC.....	82
switching on.....	81
spoiler.....	85
switching off.....	81
tracDSC.....	81
Starting after a collision.....	197
Starting the engine.....	73
active exhaust.....	75
engine block heaters.....	75
failure to start.....	74
keyless start backup.....	74
Start navigation guidance.....	128
Steering column	
lock.....	9
vehicle recovery.....	9

Steering wheel		
adjusting.....	23	
AUTO position.....	23	
heated.....	23	
Steering wheel controls		
speed limiter.....	95	
telephone.....	120	
Stop/start		
activating.....	76	
deactivating.....	76	
Storage compartments.....	65	
cup holders.....	65	
front cubby box.....	65	
rear armrest.....	65	
Storage compartments areas		
glove box.....	65	
Supplementary restraint system (SRS)		
airbag deployment.....	33	
airbag locations.....	31	
airbags maintenance.....	142	
airbag warning lamp.....	33, 40	
curtain airbags.....	32	
front airbags.....	32	
side airbags.....	32	
Suspension		
adaptive dynamics.....	87	
Switching off the engine.....	73	
Switching on the ignition.....	73	
T		
Tachometer.....	35	
Tailgate.....	6	
opening and closing.....	12	
Technical specifications		
radio frequency regulations.....	208	
weights.....	202	
wheel alignment.....	206	
Telephone.....	117	
Bluetooth compatibility.....	118	
call volume.....	121	
change the phone.....	120	
compatibility list.....	118	
hands free operation.....	118	
icons.....	120	
overview.....	117	
pairing.....	119	
via the phone.....	119	
phonebook.....	121	
safety.....	118	
steering wheel controls.....	120	
Television		
controls.....	113	
Tilt sensor.....	17	
Timed jet function.....	49	
TMC.....	132	
Touch screen.....	152	
audio/video controls.....	97	
automatic recirculation.....	63	
button feedback.....	60	
changing portable media device.....	111	
clock.....	60	
connecting multiple portable media devices.....	110	
connecting portable media devices.....	109	
DAB radio controls.....	104	
DVD player controls.....	115	
extra features.....	61	
front climate control.....	62	
heated seats.....	63	
home menu.....	59	
inhibited display.....	116	
language selection.....	60	
operating.....	60	
portable media		
controls.....	107	
portable media connections.....	108	
portable media pairing.....	110–111	
portable media playing.....	110	
radio controls.....	102	
screen settings.....	60	
setup.....	60	
shortcuts.....	60	
system settings.....	60	
telephone		
pairing.....	119	
phonebook.....	121	
touch screen care.....	60	
TV controls.....	113	

valet mode.....	61	using.....	187
video player controls.....	115	Tyres	
volume presets.....	60	age degradation.....	181
Tow eye (front).....	194	changing.....	184
Towing		flat spots.....	181
eyes.....	194	important information.....	193
tracDSC.....	81	Indian regulations.....	183
Traction control		pressures.....	177
switching between DSC and tracDSC.....	82	punctured.....	180
switching off.....	81	repair kit.....	186
switching on.....	81	repair kit use.....	187
tracDSC.....	81	repair procedure.....	187
Traffic message channel (TMC).....	134	replacements.....	180
Transmission		snow chains.....	182
automatic.....	78	speed ratings.....	177
driver controls.....		temporary use spare.....	184
.....	195	TPMS.....	184
gear shift warning lamp.....	41	warning lamp.....	40
limp home mode.....	80	TPMS pressure compensation.....	181
operation.....	82	tyre care.....	177
Transmission park release.....	195	tyre repair safety.....	186
Transmitters		tyre wall markings.....	176
smart key.....	206	use of spare tyre.....	193
Transporting the vehicle.....	195	valves.....	180
Trip computer.....	36	wall markings.....	176
average speed.....	36	wheel and tyre sizes.....	183
fuel consumption.....	36	winter.....	181
fuel range.....	37		
reset.....	36		
trip distance.....	37		
Turning on the engine			
active exhaust.....	75		
engine block heaters.....	75		
TV			
controls.....	113		
Tyre pressure checking after a repair.....	188		
Tyre pressure monitoring system (TPMS).....	184		
tyre care.....	177		
valves.....	180		
warning lamp.....	40		
Tyre repair kit			
checking pressures.....	188		
repair procedure.....	187		
safety information.....	186		

U

Under bonnet covers.....	145–146
Understeer.....	81
Unlocking.....	16
all doors.....	6
driver's door.....	6
entry and exit mode.....	23
global opening.....	6, 9
keyless entry.....	8
luggage compartment.....	10
luggage compartment emergency release.....	67
mode.....	6
multi point entry.....	6, 8
opening the tailgate.....	12
single point entry.....	6, 8

USB devices	
connecting multiple devices.....	110
Used engine oil.....	144
Using cruise control.....	96
Using the parking aids.....	90
Using the spare tyre	
important information.....	193

V

Valet mode.....	61
deselecting.....	61
Vehicle alarm.....	142
Vehicle battery	
battery monitoring system.....	160
connecting jump leads.....	160
replacing.....	162
warning symbols.....	159
Vehicle battery care.....	159
Vehicle cleaning	
airbag covers.....	152
alloy wheels.....	150
automatic car wash.....	150
carpets and mats.....	152
interior.....	151–152
parking sensors.....	91
rear screen.....	151
washer jets.....	146
Vehicle data recording.....	198
Vehicle recovery	
attaching the front tow eye.....	194
steering column lock.....	9
towing eyes.....	194
transmission park release.....	195
transporting the vehicle.....	195
Vehicle weights.....	202
Video media player	
controls.....	115
full screen view.....	116
inhibited display.....	116
VIN number.....	199
Voice guidance.....	129
Volume	
parking.....	91
telephone.....	121

W

Warning lamps.....	38
ABS.....	39
adaptive front lighting system (AFS).....	39
airbags.....	33, 40
audible warnings and indicators.....	42
automatic speed limiter.....	40
brake.....	38–39
critical warning message.....	38
cruise control.....	41
DSC active.....	40
engine/transmission.....	40
engine temperature.....	38
external temperature.....	40
gear shift warning lamp.....	41
headlamp high beam.....	41
high beam assist.....	41
indicators.....	41
intelligent stop/start (green).....	41
lamp test.....	38
parking brake.....	39
rear fog lamps.....	40
seat belt.....	39
side lights.....	41
tyre pressure monitoring system (TPMS).....	40
Warning triangle.....	148
Washer jets.....	146
Washers.....	48
fluid specification.....	158
fluid top up.....	158
headlamps.....	49
timed jet function.....	49
windscreen.....	49
Washing	
automatic car wash.....	150
exterior paintwork.....	150
removing grease.....	151
removing stains.....	152
removing tar.....	151
Weights.....	202
Wheel balancing.....	143

Wheel changing	
important information.....	193
locking wheel nuts.....	192
recommended process.....	191
safety warnings.....	190
tilt sensor.....	191
use of spare tyre.....	193
Wheels and tyres	
age degradation.....	181
changing a tyre.....	184
checking the pressures after a repair.....	188
flat spots.....	181
Indian regulations.....	183
pressures.....	177
punctured.....	180
puncture repair.....	186
puncture repair safety.....	186
repair kit.....	186
repair kit use.....	187
repair procedure.....	187
replacements.....	180
snow chains.....	182
specified sizes.....	183
temporary use spare.....	184
TPMS.....	184
TPMS pressure compensation.....	181
TPMS warning lamp.....	40
tyre care.....	177
tyre speed ratings.....	177
tyre wall markings.....	176
valves.....	180
wheel alignment.....	206
winter tyres.....	181
Wheel spin.....	81
Windows	
anti-trap protection.....	58
driver controls.....	
operation.....	58
reset.....	148
Winter tyres.....	181
Wipers and washers.....	48
drip wipe.....	49
driver controls.....	
fluid level.....	158
rain sensor.....	48
speed-dependent mode.....	48
timed washer jet function.....	49
windscreen washers.....	49
X	
Xenon headlamps.....	146

