030F7-03

## TORQUE SPECIFICATION

## 1AZ-FE

Part[Tightened	N·m	kgf[̞¢m	ft∏bf
Oil[pressure[switch]x[Cylinder[head	15	152	11
Oil[pump[x[Cylinder[block	19	194	14
Oil@train@lug@t@il@an@sub-assy	25	255	18

## 2AZ-FE

Part[Tightened	N⋅m	kgf <u>[</u> ¢m	ft[]bf
Oil[pressure[switch]x[Cylinder[head	15	152	11
Oil[pump[x[Cylinder[block	19	194	14
Oil[drain[plug]x[Dil[pan[sub-assy	25	255	18
Oil[cooler[x[Union	79	800	58
Oil[cooler[k]Cylinder[block	9.0	92	80[]n.[]bf

## 1MZ-FE

Part[Tightened		N·m	kgf <u>r</u> ¢m	ft⊡bf
Oil pressure witch cylinder block		15	152	11
DrainplugkDilpumpsub-assemblyNo.2		45	459	33
Oil[pump[assembly[x[Cylinder[block]] 10[	mm[head	8	82	71[jn.[jbf
(See[page 17-12])[ 12[i	mm[head	20	199	14
14[	mm[head	43	439	32
Crank[position[sensor[x]Oil[pump[assembly		8	82	71[jn.[jbf
Oil[pan[sub-assembly]k[Cylinder[block]]	mm[head	8	82	71[jn.[jbf
(See[page 17-12)[] 12[i	mm[head	20	199	14
Oil[strainer[x[Main[bearing[cap		8	82	71 [jn.[jbf
Oil[pan[sub-assembly[No.2[x[Oil[pan[sub-assembly[No.1		8	82	71 [jn.[jbf
Transverse@engine@engine@mounting@bracket@cylinder@block	Bolt⊡A	54	550	40
(See[page 17-12)[]	Nut⊡B	54	550	40
Transverse engine engine mounting bracket x PS pump bracket		43	439	32
Engine mounting insulator RH x Engine mounting bracket		95	969	70
Engine mounting insulator RH x Front frame		87	887	64
Engine mounting insulator FR x Cylinder block		87	887	64
Engine mounting insulator FR x Front frame		52	531	38
Oil level gage guide x Cylinder block		8	82	71 in.·lbf
Compressor mounting bracket No.1 x Cylinder block		25	250	18
Generator bracket No.2 x Transverse engine engine mounting bracket	cket	28	286	21
Timing belt idler sub-assembly No.1 x Cylinder block	_	34	347	25
Compressor and magnetic clutch x Compressor mounting bracket		25	250	18
Front suspension brace sub-assembly upper center x Body		80	816	59
Front wheel		103	1051	76