



- \* 1 : Automatic A/C
- \* 2 : Manual A/C
- \* 3 : 1MZ-FE
- \* 4 : 1M2-FE \* 4 : 2AZ-FE \* 5 : Separate Type Amplifier \* 6 : Built-In Type Amplifier \* 7 : USA

- \* 8 : Canada
- \* 9 : w/ Navigation System
- \*10 : w/o Navigation System \*11 : TMC Made
- \*12 : TMMK Made





# O : Parts Location

Code		See Page	Code		See Page	Code		See Page
A13	Α	42	C7	Α	42	R2	Α	43
A36		42	C8	В	42	R3	В	43
A40	В	42		10	42	R4		43
В6	Α	42	C11		42	R	5	43
C4		42	G3		43	R13		43
C5	Α	42	H10		43	S	4	43
	В	42	J.	4	43	S	5	43

### : Relay Blocks

	Code	See Page	Relay Blocks (Relay Block Location)	
-	1	22	Engine Room R/B (Engine Compartment Left)	

## : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
2E	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)	
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
2R	29	Instrument Paner Wire and Driver Side 3/D (Lower Philist Paner)	
3A	34	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)	
3B	34	monument and which and i assunger olde ord (monument) and blace ((1))	

### : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IH1	IH1 50	Instrument Panel Wire and Instrument Panel No.2 Wire (Instrument Panel Brace RH)	
IH2			

# : Ground Points

Code	See Page	Ground Points Location	
II	50	Cowl Side Panel LH	
IJ	50	Instrument Panel Brace LH	
IK	] 30	Instrument Faner Brace Lin	