

## REAR FLOOR NO.2 CROSSMEMBER (ASSY)

## **REPLACEMENT**

1. REMOVE REAR FLOOR NO.2 CROSSMEMBER



## 2. INSTALL REAR FLOOR NO.2 CROSSMEMBER



- 3. MEASURING THE UNDER BODY DIMENSIONS (See page BP-100)
- 4. APPLYING SEALER TO THE INSIDE OF THE VEHICLE (See page PC-1)
- 5. APPLYING SEALER TO THE REAR LUGGAGE COMPARTMENT (See page PC-1)
- 6. APPLYING UNDER COATING (See page PC-6)
- 7. INSTALL SILENCER SHEET (See page PC-11)
- 8. APPLYING ANTI-RUST AGENT
- (a) After applying the top coat layer, apply the anti-rust agent to the inside of the necked section structoral weld spots.