
IGNITION OR STARTER SWITCH ASSY (1MZ-FE/3MZ-FE) REPLACEMENT

190SQ-03

The installation procedures are the removal procedures in reverse order.

- 1. REMOVE DISCONNECT BATTERY NEGATIVE TERMINAL
- 2. REMOVE INSTRUMENT PANEL SUB-ASSY UPPER (See page 71-16)



3. REMOVE IGNITION OR STARTER SWITCH ASSY

- (a) Disconnect the ignition switch connector and unlock warning switch connector.
- (b) Remove the clamp.
- (c) Remove the 2 screws and ignition switch.