
190SP-03

IGNITION OR STARTER SWITCH ASSY (2AZ-FE)(From July, 2003)

REPLACEMENT

- 1. **DISCONNECT BATTERY NEGATIVE TERMINAL**
- 2. REMOVE INSTRUMENT PANEL SUB-ASSY UPPER (See page 71-16)

The installation procedures are the removal procedures in reverse order.



3. REMOVE IGNITION OR STARTER SWITCH ASSY

- (a) Disconnect the ignition switch connector and unlock warning switch connector.
- (b) Remove the clamp.
- Remove the 2 screws and ignition switch. (c)