
Connector Joining Wire Harness and Wire Harness



| | Code | Joining Wire Harness and Wire Harness (Connector Location) |
|---|------|--|
| ľ | BA1 | Rear Door LH Wire and Floor No.2 Wire (Left Center Pillar) |
| Ī | BB1 | Rear Door RH Wire and Floor Wire (Right Center Pillar) |