
DRIVE BELT (1MZ-FE)


REPLACEMENT

- 1. REMOVE FRONT WHEEL RH
- 2. REMOVE FRONT FENDER APRON SEAL RH




3. REMOVE V (COOLER COMPRESSOR TO **CRANKSHAFT PULLEY) BELT NO.1**

- Loosen the bolt A and B. (a)
- (b) Loosen the adjusting bolt C, and remove the V-ribbed belt.



4. **REMOVE VANE PUMP V BELT**

Loosen the bolt A and B, and remove the V-ribbed belt. (a)



5. **INSTALL VANE PUMP V BELT**

- (a) Install the V-ribbed belt on each pulley.
- Using a bar, adjust the V-ribbed belt tension and tighten (b) the bolt B.


Torque: 43 N·m (439 kgf·cm, 32 ft·lbf)

Tighten the bolt A. (c)

INSTALL V

Torque: 43 N·m (439 kgf·cm, 32 ft·lbf)

CRANKSHAFT PULLEY) BELT NO.1



Install the V-ribbed belt on each pulley.

- (a)
- (b) Tighten the adjusting bolt C, and adjust the V-ribbed belt tension.

(COOLER

COMPRESSOR TO

First tighten the bolt A, then B. (c)

Torque:

Bolt A 58 N·m (591 kgf·cm, 43 ft·lbf)

Bolt B 18 N·m (184 kgf·cm, 13 ft·lbf)

CAMRY REPAIR MANUAL (RM915E)

7. INSPECT[DRIVE[BELT[DEFLECTION[AND[TENSION(REFERENCE)][See[page]]4-137)

B. INSTALL FRONT WHEEL RH

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)