
DISPLAY PANEL DOES NOT OPEN, TILT, OR TILTS IMPROPERLY

INSPECTION PROCEDURE

1 CHECK RADIO AND NAVIGATION ASSY



(a) Check[for[foreign[matter[pr[bbstructions[caught[n]the moving[parts[pf[the]panel.

Standard: [No obstruction or foreign matter is found.

NG

 $\begin{array}{ll} REMOVE [] ANY [] OBSTRUCTION [] OR [] FOREIGN \\ MATTER [FOUND \\ \end{array}$

OK

2 | OPERATION CHECK

(a) Check[]f[]he[]havigation[]and[]audio[]systems[]unction[]properly.

Standard:[Navigation[]and[]audio[]systems[]function[]properly.

OK \

REPLACE RADIO AND NAVIGATION ASSY (SEE PUB. NO. RM915E, PAGE 67-4)

NG

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE[PAGE[05-46)