
Position of Parts in Body

[RHD]



- L 1 License Plate Light LH
- L 2 License Plate Light RH
- L 3 Light Failure Sensor
- L 4 Luggage Compartment Door Opener Motor Luggage Compartment Light SW
- L 5 Luggage Compartment Light
- M 1 Mirror Heater LH Remote Control Mirror LH
- M 2 Mirror Heater RH
- Remote Control Mirror RH
- M 3 Moon Roof Control ECU and Motor
- M 4 Moon Roof Control SW Personal Light
- N 2 Navigation ECU
- N 3 Navigation ECU
- N 4 Noise Filter

- P 6 Power Window Control SW Front LH
- P 8 Power Window Control SW Rear LH
- P 9 Power Window Control SW Rear RH
- P10 Power Window Motor Front LH
- P 11 Power Window Motor Front RH
- P12 Power Window Motor Rear LH
- P13 Power Window Motor Rear RH
- P14 Pretensioner LH
- P15 Pretensioner RH
- R12 Rain Sensor
- R13 Rear Combination Light LH
- R14 Rear Combination Light RH
- R15 Rear Speaker LH
- R16 Rear Speaker RH
- R17 Rear Window Defogger
- R18 Rear Window Defogger
- R19 Remote Control Mirror SW
- S15 Side Airbag Sensor LH
- S16 Side Airbag Sensor RH
- V 7 Vanity Light LH
- V 8 Vanity Light RH