
Connector Joining Wire Harness and Wire Harness



	Code	Joining Wire Harness and Wire Harness (Connector Location)
ſ	BA1	Rear Door LH Wire and Floor No.2 Wire (Left Center Pillar)
ſ	BB1	Rear Door RH Wire and Floor Wire (Right Center Pillar)