## **TERMS**

## **ABBREVIATIONS USED IN THIS MANUAL**

0106L-03

Abbreviations	Meaning
ABS	Anti-Lock Brake System
A/C	Air Conditioner
AC	Alternating Current
ACC	Accessory
ACIS	Acoustic Control Induction System
ACSD	Automatic Cold Start Device
A.D.D.	Automatic Disconnecting Differential
A/F	Air-Fuel Ratio
AHC	Active Height Control Suspension
ALR	Automatic Locking Retractor
ALT	Alternator
AMP	Amplifier
ANT	Antenna
APPROX.	Approximately
ASSY	Assembly
A/T	Automatic Transmission (Transaxle)
ATF	Automatic Transmission Fluid
AUTO	Automatic
AUX	Auxiliary
AVG	Average
AVS	Adaptive Variable Suspension
B+	Battery Voltage
BACS	Boost Altitude Compensation System
BAT	Battery
BDC	Bottom Dead Center
B/L	Bi-Level
B/S	Bore-Stroke Ratio
BTDC	Before Top Dead Center
BVSV	Bimetallic Vacuum Switching Valve
CB	Circuit Breaker
CCo	Catalytic Converter For Oxidation
CD	Compact Disc
CF	Cornering Force
CG	Center Of Gravity
CH	Channel
CKD	Complete Knock Down
COMB.	Combination
CPE CPS	Coupe Combustion Procesure Songer
	Combustion Pressure Sensor
CPU	Central Processing Unit
CRS	Child Restraint System
CTR	Center
C/V	Check Valve
CV	Control Valve
CW	Curb Weight
DC	Direct Current
DEF	Defogger
DFL	Deflector

Abbreviations	Meaning
DIFF.	Differential
DIFF. LOCK	Differential Lock
D/INJ	Direct Injection
DLC	Data Link Connector
DLI	Distributorless Ignition
DOHC	Double Overhead Cam
DP	Dash Pot
DS	Dead Soak
DSP	Digital Signal Processor
DTC	Diagnostic Trouble Code
ECAM	Engine Control And Measurement System
ECD	Electronic Controlled Diesel
ECDY	Eddy Current Dynamometer
ECT	Electronic Control Transmission
ECU	Electronic Control Unit
ED	Electro-Deposited Coating
EDU	Electronic Driving Unit
EDIC	Electric Diesel Injection Control
EFI	Electronic Fuel Injection
E/G	Engine
EGR	Exhaust Gas Recirculation
EGR-VM	EGR-Vacuum Modulator
ELR	
ENG	Emergency Locking Retractor Engine
	-
ESA	Electronic Spark Advance
ETCS	Electronic Throttle Control System
EVAP	Evaporative Emission Control
EVP	Evaporator Development State No. 1
E-VRV	Electric Vacuum Regulating Valve
EX	Exhaust
FE	Fuel Economy
FF Trip	Front-Engine Front-Wheel-Drive
F/G	Fuel Gauge
FIPG	Formed In Place Gasket
FL	Fusible Link
F/P	Fuel Pump
FPU	Fuel Pressure Up
FR	Front
F/W	Flywheel
FW/D	Flywheel Damper
FWD	Front-Wheel-Drive
GAS	Gasoline
GND	Ground
HAC	High Altitude Compensator
H/B	Hatchback
H-FUSE	High Current Fuse
Н	High
HID	High Intensity Discharge (Head Lamp)
HSG	Housing
НТ	Hard Top

Abbreviations	Meaning
IC	Integrated Circuit
IDI	Indirect Diesel Injection
IFS	Independent Front Suspension
IG	Ignition
IIA	Integrated Ignition Assembly
IN	Intake (Manifold, Valve)
INT	Intermittent
I/P	Instrument Panel
IRS	Independent Rear Suspension
ISC	Idle Speed Control
J/B	Junction Block
J/C	Junction Connector
KD	Kick-Down
LAN	Local Area Network
LB	Liftback
LCD	Liquid Crystal Display
LED	Light Emitting Diode
LH	Left-Hand
LHD	Left-Hand Drive
L/H/W	Length, Height, Width
LLC	Long-Life Coolant
LNG	Liquified Natural Gas
LO	Low
LPG	Liquified Petroleum Gas
LSD	Limited Slip Differential
	·
LSP & PV LSPV	Load Sensing Proportioning And Bypass Valve  Load Sensing Proportioning Valve
MAP	Manifold Absolute Pressure
MAX.	Maximum  Maximum
MIC	Microphone
MIL	Malfunction Indicator Lamp
MIN.	Minimum
MP	Multipurpose
MPI	Multipoint Electronic Injection
MPX	Multiplex Communication System
M/T	Manual Transmission
MT	Mount
MTG	Mounting
N	Neutral
NA	Natural Aspiration
NO.	Number
028	Oxygen Sensor
O/D	Overdrive
OEM	Original Equipment Manufacturing
ОНС	Overhead Camshaft
OHV	Overhead Valve
OPT	Option
O/S	Oversize
P & BV	Proportioning And Bypass Valve
PCS	Power Control System
PCV	Positive Crankcase Ventilation

	Abbreviations	Meaning
PKB		Parking Brake
PPS		Progressive Power Steering
PS		Power Steering
PTO		Power Take-Off
P/W		Power Window
R&P		Rack And Pinion
R/B		Relay Block
RBS		Recirculating Ball Type Steering
R/F		Reinforcement
RFS		Rigid Front Suspension
RRS		Rigid Rear Suspension
RH		Right-Hand
RHD		Right-Hand Drive
RLY		Relay
ROM		Read Only Memory
RR		Rear
RRS		Rear-Wheel Drive
RWD		Rear-Wheel Drive
SDN		Sedan
SEN		Sensor
SICS		Starting Injection Control System
SOC		State Of Charge
SOHC		Single Overhead Camshaft
SPEC		Specification
SPI		Single Point Injection
SRS		Supplemental Restraint System
SSM		Special Service Materials
SST		Special Service Tools
STD		Standard Standard
STJ		Cold-Start Fuel Injection
SW		Switch
SYS		System
T/A		Transaxle
TACH		Tachometer
TBI		Throttle Body Electronic Fuel Injection
TC		Turbocharger
TCCS		TOYOTA Computer-Controlled System
TCV		Timing Control Valve
TDC		Top Dead Center
TEMP.		Temperature
TEMS		TOYOTA Electronic Modulated Suspension
TFT		Toyota Free-Tronic
TIS		Total Information System For Vehicle Development
T/M		Transmission
TMC		TOYOTA Motor Corporation
TMMK		TOYOTA Motor Manufacturing Kentucky, Inc.
TRC		Traction Control System
TURBO		Turbocharge
TWC		Three-Way Catalyst
U/D		Underdrive
U/S		Undersize
0/0		0110013120

Abbreviations	Meaning	
VCV	Vacuum Control Valve	
VENT	Ventilator	
VIN	Vehicle Identification Number	
VPS	Variable Power Steering	
VSC	Vehicle Skid Control	
VSV	Vacuum Switching Valve	
VTV	Vacuum Transmitting Valve	
VVT-i	Variable Valve Timing-intelligent	
W/	With	
WGN	Wagon	
W/H	Wire Harness	
W/O	Without	
1ST	First	
2ND	Second	
2WD	Two Wheel Drive Vehicle (4 x 2)	
3RD	Third	
4TH	Fourth	
4WD	Four Wheel Drive Vehicle (4 x 4)	
4WS	Four Wheel Steering System	
5TH	Fifth	