## **Inside-the-Plate Wiring Connection Diagram**

When conducing continuity test inside the plate, see the plate and terminal ID number (View 1) shown below as well as the inside-the-plate wiring connection diagram

