


\* 3 : TMMK Made \* 4 : TMC Made



## : Parts Location

| Code |   | See Page | Code |   | See Page | Code |   | See Page |
|------|---|----------|------|---|----------|------|---|----------|
| В6   | Α | 42       | D8   | Α | 44       | J23  |   | 43       |
| B8   | С | 42       | D0   | В | 44       | L4   |   | 45       |
| C7   | Α | 42       | D9   | Α | 44       | L5   |   | 45       |
| C8   | В | 42       | פט   | В | 44       | N4   |   | 45       |
| D4   |   | 44       | G4   |   | 44       | V9   | Α | 45       |
| D6   | Α | 44       | I1   | 3 | 43       | ٧٥   | В | 45       |
|      | В | 44       | l14  |   | 43       | V10  | Α | 45       |
| D7   | Α | 44       | 117  | Α | 44       | V 10 | В | 45       |
| "    | В | 44       |      | В | 44       |      |   |          |

## : Junction Block and Wire Harness Connector

| Code | See Page | Junction Block and Wire Harness (Connector Location)                     |  |  |  |
|------|----------|--|--|--|--|
| 2B   | 28       | Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)           |  |  |  |
| 2K   | 28       | Floor Wire and Driver Side J/B (Lower Finish Panel)                      |  |  |  |
| 2M   | 2M       |  |  |  |  |
| 2Q   | 29       | Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)           |  |  |  |
| 2R   | 129      |  |  |  |  |
| 2S   | 1        |  |  |  |  |
| 3A   | 34       | Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH) |  |  |  |

## : Connector Joining Wire Harness and Wire Harness

| Code | See Page | Joining Wire Harness and Wire Harness (Connector Location)        |  |
|------|----------|---|--|
| IC2  | 50       | Instrument Panel Wire and Floor Wire (Left Kick Panel)            |  |
| IE1  | 50       | Instrument Panel Wire and Roof Wire (Inside of Front Left Pillar) |  |
| IN4  | 51       | Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)      |  |

## : Ground Points

| Code | See Page | Ground Points Location            |  |
|------|----------|-----------------------------------|--|
| II   | 50       | Cowl Side Panel LH                |  |
| IJ   | 50       | Instrument Panel Brace LH         |  |
| IM   | 50       | Instrument Panel Reinforcement RH |  |