## MULTIPLEX COMMUNICATION SYSTEM HOW TO PROCEED WITH TROUBLESHOOTING

055V6\_04

HINT:

Troubleshoot in acc	cordance with	the proced	dure on the	following	pages.
---------------------	---------------	------------	-------------	-----------	--------

1 VEHICLE BROUGHT TO WORKSHOP

2 SYMPTOM CHECK

3 INSPECT COMMUNICATION FUNCTION OF LARGE-SCALE MULTIPLEX COMMUNICATION SYSTEM (BEAN)

- (a) Check that there is no abnormality in the communication system by inspecting the communication function of the multiplex communication system.
  - (1) (ECU communication stop, communication line abnormal) With code outputs, proceed to A.
  - (2) (ECU communication stop, communication line abnormal) Without code outputs, proceed to B.

B GO TO SECTION OF EACH SYSTEM

Α\_\_

## 4 DIAGNOSTIC TROUBLE CODE CHECK (See page 05–2150)

- (a) Check a DTC and note it if a code is output.
- (b) Delete the DTC.
- (c) Check if the DTC will be output once again, when the problem symptom is simulated based on the noted code.
  - (1) When no code is output (symptom check and simulation is possible), proceed to A.
  - (2) When no code is output (symptom check and simulation is impossible), proceed to B.
  - (3) When a code is output, proceed to "C".

B GO TO PROBLEM SIMULATION (See page 05–2156)

C Go to step 7

A

- 5 PROBLEM SYMPTOMS TABLE (See page 05–2156)
- (a) Without applicable symptoms, proceed to A.
- (b) With applicable symptoms, proceed to B.

B Go to step 7

\_A\_

6	PERFORM TROUBLESHOOTING IN FOLLOWING METHOD, DEPENDING ON
	MALFUNCTION SYMPTOM

- (a) Pre-check (See page 05-2150).

(b) Terminals of ECU (See page 05–2154).						
7	7 ADJUSTMENT, REPAIR OR REPLACEMENT					
EN	1D					