## **CHECK MODE PROCEDURE**

05MDJ-01

- 1. CHECK MODE (SIGNAL CHECK) (USING INTELLIGENT TESTER II)
- (a) Connect the intelligent tester II to the DLC3.
- (b) Turn the ignition switch to the ON position.
- (c) Select the "SIGNAL CHECK", and proceed checking with the intelligent tester II.