SOUND QUALITY IS BAD ONLY WHEN CD IS PLAYED (VOLUME IS TOO LOW)

INSPECTION PROCEDURE

- 1 REPLACE CD WITH ANOTHER AND RECHECK
- (a) Replace the CD with another one and recheck.
 - (1) Replace the CD with another normal one to see if the same trouble occurs again.

OK: Malfunction disappears.



REPLACE RADIO RECEIVER ASSY (SEE PAGE

OK

CD IS FAULTY