

: Parts Location

Code	See Page	Code	See Page	Code	See Page
C4	42	P4	43		
J4	43	P5	43		

: Junction Block and Wire Harness Connector

	Code	See Page	Junction Block and Wire Harness (Connector Location)	
Γ	2A	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	

∇

: Ground Points

Code	See Page	Ground Points Location
IK	50	Instrument Panel Brace LH