
## STEREO COMPONENT AMPLIFIER ASSY REPLACEMENT

67002 02

HINT:

COMPONENTS: See page 67-1

- 1. REMOVE FRONT DOOR SCUFF PLATE RH (See page 71–16)
- 2. REMOVE COWL SIDE TRIM SUB-ASSY RH (See page 71-16)
- 3. REMOVE INSTRUMENT PANEL UNDER COVER SUB-ASSY NO.1 (See page 71-16)
- 4. REMOVE GLOVE COMPARTMENT DOOR PAD (See page 71–16)
- 5. REMOVE INSTRUMENT PANEL SUB-ASSY LOWER (See page 71-16)



## 6. REMOVE STEREO COMPONENT AMPLIFIER ASSY

- (a) Disconnect the connectors.
- (b) Remove the 2 nuts and stereo component amplifier assy.