


The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other Parts.







## J POWER SOURCE (Current Flow Chart)

## Engine Room J/B (See Page 24)

Fuse	System	Page
ALT-S	1	68
		248
ST		60
	,	64
	,	182
	, , , , , , , , , , , , , , , , , , , ,	188
ETCS	Engine Control (1MZ–FE, 3MZ–FE)	70
	Engine Control (2AZ–FE)	82
LIEAD LILLIDD	Headlight	114
HEAD LH UPR	Multiplex Communication System (BEAN)	98
	Headlight	114
HEAD RH UPR	Multiplex Communication System (BEAN)	98
	Horn	226
HORN	Multiplex Communication System (BEAN)	98
	Theft Deterrent and Door Lock Control	142
	ABS (w/o VSC TMC Made)	166
	ABS (w/o VSC TMMK Made)	170
	ABS (w/ VSC), TRAC and VSC	160
	Charging	68
	Combination Meter	248
	Cruise Control (1MZ-FE, 3MZ-FE)	182
IG2	Cruise Control (2AZ–FE)	188
	Electronically Controlled Transmission and A/T Indicator (1MZ–FE, 3MZ–FE)	194
	Electronically Controlled Transmission and A/T Indicator (2AZ–FE)	200
	Engine Control (1MZ–FE, 3MZ–FE)	70
	Engine Control (2AZ–FE)	82
	Seat Belt Warning	214
	SRS	175
HAZ	Turn Signal and Hazard Warning Light	132
	Clock	234
	Engine Control (1MZ–FE, 3MZ–FE)	70
IGN	Engine Control (2AZ-FE)	82
1014	Engine Immobiliser System	94
	Starting and ignition (1MZ–FE, 3MZ–FE)	60
	Starting and ignition (2AZ–FE)	64
	Cruise Control (1MZ-FE, 3MZ-FE)	182
	Cruise Control (2AZ–FE)	188
EFI	Electronically Controlled Transmission and A/T Indicator (1MZ–FE, 3MZ–FE)	194
	Electronically Controlled Transmission and A/T Indicator (2AZ–FE)	200
	Engine Control (1MZ–FE, 3MZ–FE)	70
	Engine Control (2AZ–FE)	82
	ST  ETCS  HEAD LH UPR  HORN  IG2  HAZ	ALT-S  Charging  Combination Meter  Starting and ignition (1MZ-FE, 3MZ-FE)  Starting and ignition (1MZ-FE, 3MZ-FE)  Cruise Control (1MZ-FE, 3MZ-FE)  Cruise Control (1MZ-FE, 3MZ-FE)  Engine Control (2AZ-FE)  Engine Control (2AZ-FE)  Engine Control (2AZ-FE)  Engine Control (2AZ-FE)  HEAD LH UPR  Headlight  Multiplex Communication System (BEAN)  Headlight  Multiplex Communication System (BEAN)  Horn  HORN  Multiplex Communication System (BEAN)  Theft Deterrent and Door Lock Control  ABS (w/o VSC TMC Made)  ABS (w/o VSC TMK Made)  ABS (w/o VSC, TRAC and VSC  Charging  Combination Meter  Cruise Control (1MZ-FE, 3MZ-FE)  Electronically Controlled Transmission and A/T Indicator (1MZ-FE, 3MZ-FE)  Electronically Controlled Transmission and A/T Indicator (2AZ-FE)  Engine Control (1MZ-FE, 3MZ-FE)  Engine Control (2AZ-FE)  Engine Control (1MZ-FE, 3MZ-FE)  Clock  Engine Control (2AZ-FE)  Engine Immobiliser System  Starting and ignition (1MZ-FE, 3MZ-FE)  Starting and ignition (1MZ-FE, 3MZ-FE)  Cruise Control (1MZ-FE, 3MZ-FE)  Cruise Control (1MZ-FE, 3MZ-FE)  Electronically Controlled Transmission and A/T Indicator (1MZ-FE, 3MZ-FE)  Engine Control (1MZ-FE, 3MZ-FE)  Engine Control (1MZ-FE, 3MZ-FE)

<sup>\*</sup> These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
25A	A/F	Engine Control (1MZ-FE, 3MZ-FE)	70
		Multiplex Communication System (BEAN)	98
25A	DOOR1	Theft Deterrent and Door Lock Control	142
		Wireless Door Lock Control	148
30A	ABS NO.3	ABS (w/o VSC TMMK Made)	170
30A	ABS NO.3	ABS (w/ VSC), TRAC and VSC	160
30A	ADJ PDL	Power Adjustable Pedals	232
		Charging	68
		Engine Control (1MZ-FE, 3MZ-FE)	70
30A	AM2	Engine Control (2AZ–FE)	82
		Starting and ignition (1MZ-FE, 3MZ-FE)	60
		Starting and ignition (2AZ–FE)	64
30A	CDS	Radiator Fan and Condenser Fan	254
30A	RDI	Radiator Fan and Condenser Fan	254
40A	ABS NO.2	ABS (w/o VSC TMC Made)	166
		Automatic Light Control	120
		Combination Meter	248
40A	MAIN	Fog Light	118
40A		Headlight	114
		Light Auto Turn Off System	122
		Multiplex Communication System (BEAN)	98
	HTR	Automatic Air Conditioning (1MZ–FE)	260
50A		Automatic Air Conditioning (2AZ–FE)	266
50A		Manual Air Conditioning (1MZ-FE, 3MZ-FE)	272
		Manual Air Conditioning (2AZ-FE)	278

# **Driver Side J/B (See Page 28)**

Fuse		System	Page
		Electronically Controlled Transmission and A/T Indicator (1MZ–FE, 3MZ–FE)	194
		Electronically Controlled Transmission and A/T Indicator (2AZ–FE)	200
5A	AM1	Engine Control (1MZ–FE, 3MZ–FE)	70
		Engine Control (2AZ–FE)	82
		Starting and ignition (1MZ-FE, 3MZ-FE)	60
		Starting and ignition (2AZ–FE)	64
		Clock	234
5A	ECU-ACC	Combination Meter	248
J SA		Multiplex Communication System (BEAN)	98
		Remote Control Mirror	218
		Clock	234
	DOME	Garage Door Opener	222
7.5A		Interior Light	124
		Multiplex Communication System (BEAN)	98
		Wireless Door Lock Control	148

<sup>\*</sup> These are the page numbers of the first page on which the related system is shown.

## J POWER SOURCE (Current Flow Chart)

	Fuse	System	Page
7.5A	OBD	Engine Control (1MZ-FE, 3MZ-FE)	70
7.54	OBD	Engine Control (2AZ–FE)	82
		ABS (w/o VSC TMC Made)	166
		ABS (w/o VSC TMMK Made)	170
		ABS (w/ VSC), TRAC and VSC	160
		Automatic Air Conditioning (1MZ–FE)	260
		Automatic Air Conditioning (2AZ–FE)	266
		Automatic Light Control	120
		Clock	234
		Combination Meter	248
		Cruise Control (1MZ–FE, 3MZ–FE)	182
		Cruise Control (2AZ–FE)	188
		Electronically Controlled Transmission and A/T Indicator (1MZ–FE, 3MZ–FE)	194
		Electronically Controlled Transmission and A/T Indicator (2AZ–FE)	200
		Engine Control (1MZ–FE, 3MZ–FE)	70
		Engine Control (2AZ–FE)	82
10A	ECU-B	Engine Immobiliser System	94
		Headlight	114
		Illumination	128
		Interior Light	124
		Key Reminder	140
		Light Auto Turn Off System	122
		Manual Air Conditioning (1MZ-FE, 3MZ-FE)	272
		Manual Air Conditioning (2AZ-FE)	278
		Moon Roof	154
		Multiplex Communication System (BEAN)	98
		Navigation System, Audio System	238
		Power Window	156
		Seat Belt Warning	214
		SRS	175
		Theft Deterrent and Door Lock Control	142
		Wireless Door Lock Control	148
		ABS (w/o VSC TMC Made)	166
		ABS (w/o VSC TMMK Made)	170
		ABS (w/ VSC), TRAC and VSC	160
		Automatic Light Control	120
		Headlight	114
10A	ECU-IG	Interior Light	124
***		Key Reminder	140
		Light Auto Turn Off System	122
		Moon Roof	154
		Multiplex Communication System (BEAN)	98
		Power Window	156
		Theft Deterrent and Door Lock Control	142

<sup>\*</sup> These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
10A	FAN RLY	Radiator Fan and Condenser Fan	254
		Charging	68
		Clock	234
		Combination Meter	248
		Cruise Control (1MZ–FE, 3MZ–FE)	182
		Cruise Control (2AZ-FE)	188
		Electronically Controlled Transmission and A/T Indicator (1MZ–FE, 3MZ–FE)	194
		Electronically Controlled Transmission and A/T Indicator (2AZ–FE)	200
404	0.411054	Engine Control (1MZ–FE, 3MZ–FE)	70
10A	GAUGE1	Engine Control (2AZ–FE)	82
		Illumination	128
		Key Reminder	140
		Multiplex Communication System (BEAN)	98
		Navigation System, Audio System	238
		Seat Belt Warning	214
		Shift Lock	206
		SRS	175
		Turn Signal and Hazard Warning Light	132
		ABS (w/o VSC TMC Made)	166
		ABS (w/o VSC TMMK Made)	170
		ABS (w/ VSC), TRAC and VSC	160
		Automatic Glare–Resistant EC Mirror	220
		Back-Up Light	138
		Cruise Control (1MZ–FE, 3MZ–FE)	182
		Cruise Control (2AZ–FE)	188
10A	GAUGE2	Electronically Controlled Transmission and A/T Indicator (1MZ–FE, 3MZ–FE)	194
		Electronically Controlled Transmission and A/T Indicator (2AZ–FE)	200
		Engine Control (1MZ–FE, 3MZ–FE)	70
		Engine Control (2AZ–FE)	82
		Moon Roof	154
		Multiplex Communication System (BEAN)	98
		Navigation System, Audio System	238
		Power Adjustable Pedals	232
		Rear Window Defogger and Mirror Heater	230
		Automatic Air Conditioning (1MZ–FE)	260
10A	HTR	Automatic Air Conditioning (2AZ–FE)	266
		Manual Air Conditioning (1MZ–FE, 3MZ–FE)	272
		Manual Air Conditioning (2AZ–FE)	278
464	AUD LITE	Engine Control (1MZ–FE, 3MZ–FE)	70
10A	MIR HTR	Engine Control (2AZ–FE)	82
		Rear Window Defogger and Mirror Heater	230
10A	PANEL	Clock	234
		Illumination	128

<sup>\*</sup> These are the page numbers of the first page on which the related system is shown.

## J POWER SOURCE (Current Flow Chart)

	Fuse	System	Page
		Audio System (Built-In Type Amplifier w/o Navigation System)	246
10A	RAD NO.2	Audio System (Separate Type Amplifier w/o Navigation System)	242
		Navigation System, Audio System	238
		Engine Control (1MZ-FE, 3MZ-FE)	70
10A	TAIL	Engine Control (2AZ–FE)	82
		Taillight	134
15A	CIG	Power Outlet and Cigarette Lighter	224
15A	FOG	Fog Light	118
15A	POWER POINT	Power Outlet and Cigarette Lighter	224
		ABS (w/o VSC TMC Made)	166
		ABS (w/o VSC TMMK Made)	170
		ABS (w/ VSC), TRAC and VSC	160
		Cruise Control (1MZ–FE, 3MZ–FE)	182
		Cruise Control (2AZ–FE)	188
15A	STOP	Electronically Controlled Transmission and A/T Indicator (1MZ–FE, 3MZ–FE)	194
		Electronically Controlled Transmission and A/T Indicator (2AZ–FE)	200
		Engine Control (1MZ–FE, 3MZ–FE)	70
		Engine Control (2AZ–FE)	82
		Shift Lock	206
		Stop Light	136
15A	WASHER	Wiper and Washer	228
		Audio System (Built–In Type Amplifier w/o Navigation System)	246
20A	RAD NO.1	Audio System (Separate Type Amplifier w/o Navigation System)	242
		Navigation System, Audio System	238
20A	SEAT HTR	Seat Heater	212
25A	WIPER	Wiper and Washer	228
		Moon Roof	154
30A	PWR NO.1	Multiplex Communication System (BEAN)	98
		Power Window	156
30A	PWR SEAT	Power Seat	208
		Engine Control (1MZ-FE, 3MZ-FE)	70
40A	DEF	Engine Control (2AZ–FE)	82
		Rear Window Defogger and Mirror Heater	230

## **Engine Room R/B (See Page 22)**

	Fuse	System	Page
5A	DRL	Headlight	114
	DICE	Multiplex Communication System (BEAN)	98
10A	A/C	Manual Air Conditioning (1MZ–FE, 3MZ–FE)	272
ITUA		Manual Air Conditioning (2AZ–FE)	278
15A	HEAD LH LWR	Combination Meter	248
ISA	ITIEAD LITEVIN	Fog Light	118

<sup>\*</sup> These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
15A	HEAD LH LWR	Headlight	114
ISA	LUEAD FU FAK	Multiplex Communication System (BEAN)	98
15A	HEAD RH LWR	Headlight	114
13/1	TILAD KITEVIK	Multiplex Communication System (BEAN)	98
		ABS (w/o VSC TMC Made)	166
50A	ABS NO.1	ABS (w/o VSC TMMK Made)	170
		ABS (w/ VSC), TRAC and VSC	160
		Automatic Light Control	120
		Charging	68
		Clock	234
		Electronically Controlled Transmission and A/T Indicator (1MZ–FE, 3MZ–FE)	194
	ALT	Electronically Controlled Transmission and A/T Indicator (2AZ-FE)	200
		Engine Control (1MZ–FE, 3MZ–FE)	70
120A		Engine Control (2AZ–FE)	82
		Illumination	128
		Light Auto Turn Off System	122
		Multiplex Communication System (BEAN)	98
		Starting and ignition (1MZ–FE, 3MZ–FE)	60
		Starting and ignition (2AZ–FE)	64
		Taillight	134

 $<sup>\</sup>ast$  These are the page numbers of the first page on which the related system is shown.