0554Q−02

DTC	P1633/89	ECM MALFUNCTION (ETCS CIRCUIT)

CIRCUIT DESCRIPTION

Refer to DTC P1129/89 on page 05−79.

DTC No.	DTC Detection Condition	Trouble Area
P1633/89	ECM inside error	• ECM

WIRING DIAGRAM

Refer to DTC P1125/41 on page 05−73.

INSPECTION PROCEDURE

HINT:

Read freeze frame data using hand−held tester, as freeze frame data records the engine conditions when a malfunction is detected, when troubleshooting it is useful for determining whether the vehicle was running or stopped, the engine warmed up or not, the air−fuel ratio lean or rich, etc. at the time of the malfunction.

CHECK AND REPLACE ECM