## MANUAL TRANSMISSION/TRANSAXLE PREPARATION

020WL-01

**SST** 

	09308-00010	Oil Seal Puller	FRONT DIFFERENTIAL OIL SEAL
	09520-01010	Drive Shaft Remover Attachment	FRONT DIFFERENTIAL OIL SEAL
	09520-24010	Differential Side Gear Shaft Puller	FRONT DIFFERENTIAL OIL SEAL
	(09520-32040)	Shocker Set	FRONT DIFFERENTIAL OIL SEAL
	09608-10010	Steering Knuckle Oil Seal Replacer	FRONT DIFFERENTIAL OIL SEAL
	09608-32010	Steering Knuckle Oil Seal Replacer	FRONT DIFFERENTIAL OIL SEAL
	09930-00010	Drive Shaft Nut Chisel	MANUAL TRANSAXLE ASSY
	09950-70010	Handle Set	FRONT DIFFERENTIAL OIL SEAL
<b>a</b>	(09951-07200)	Handle 200	FRONT DIFFERENTIAL OIL SEAL

## **Recomended Tools**

	09011-12301	Socket Wrench 30 mm	MANUAL TRANSAXLE ASSY
The state of the s	09040-00011	Hexagon Wrench Set	MANUAL TRANSAXLE ASSY
	(09043-20060)	Socket Hexagon Wrench 6	MANUAL TRANSAXLE ASSY

## **Equipment**

Dial indicator with magnetic base	
Torque wrench	
Slide calipers	
V-block	
Micrometer	
Dial indicator	
Cylinder gauge	
Feeler gauge	
Precision straight edge	

## Lubricant

Item	Capacity	Classification
Manual transaxle oil (w/ Differential oil)	2.5 liters (2.6 US qts, 2.2 lmp. qts)	API GL-4 or GL-5 SAE 75W-90