
REPLACEMENT

HINT:

Installation is according to the reverse order of the removal.

- 1. REMOVE REAR SEAT CUSHION ASSY See page 72-21)
- 2. REMOVE[REAR[\$EAT[BACK[ASSY[See]page[72-21]]
- 3. REMOVE REAR DOOR OPENING TRIM WEATHERSTRIP RH
- 4. REMOVE REAR DOOR OPENING TRIM WEATHERSTRIP LH
- 5. REMOVE ROOF SIDE GARNISH INNER RH (W/O CURTAIN SHIELD AIR BAG) (See page 76-21)
- 6. REMOVE ROOF SIDE GARNISH INNER LH (W/O CURTAIN SHIELD AIR BAG) (See page 76-21)
- 7. REMOVE ROOF SIDE GARNISH INNER RH (W/ CURTAIN SHIELD AIR BAG) (See page 76-21)
- 8. REMOVE ROOF SIDE GARNISH INNER LH (W/ CURTAIN SHIELD AIR BAG) (See page 76-21)
- 9. REMOVE[ROOF[HEADLINING[ASSY[See[page[76-21]]
- 10. REMOVE CENTER STOP LAMP ASSY (See page 76-21)
- 11 REMOVE PACKAGE TRAY TRIM PANEL ASSY See page 76-21)



12. REMOVE BACK WINDOW MOULDING OUTSIDE

(a) Using a knife, cut off the moulding as shown in the illustration.


NOTICE:

Do not damage the body with the knife.

(b) Remove the remaining moulding.

HINT:

When removing, make a cut partly, pull and remove it by hand.




13. REMOVE BACK WINDOW GLASS

HINT:

There is a case where a 1-piece type and a 2-piece type of stoppers are installed in a vehicle type.

700BT-01




- (a) Push a piano wire through between the body and glass from the interior.
- (b) Apply protective tape to the outer surface to keep the surface from being scratched.
- (c) Tie both wire ends to wooden blocks or similar objects.

NOTICE:

- When separating the glass, take care not to damage the paint and interior/exterior ornaments.
- To prevent the piano wire to be cut, do not cross it.
- (d) Cut the adhesive by pulling the piano wire around it.
- (e) Using a suction rubber, remove the glass.

NOTICE:

Leave as much adhesive on the body as possible when cutting off the glass.



14. CLEAN BACK WINDOW GLASS


- (a) Using a scraper, remove the damaged spacers and clips, dam and adhesive sticking to the glass.
- (b) Clean the outer circumference of the glass with white gasoline.

NOTICE:

- Do not touch the glass after cleaning it.
- Be careful not to damage the body.

15. INSTALL BACK WINDOW GLASS STOPPER NO.1

(a) Install the 2 new windshield glass stoppers No.1 to the body.




16. INSTALL BACK WINDW GLASS STOPPER NO.2

(a) Coat the installation part of the stopper with Primer G.

NOTICE:

- Dry the primer coating for 3 minutes or more.
- Do not apply too much primer.
- (b) Install the 2 new windshield glass stoppers No.2 onto the glass as shown in the illustration..

A: 11.2 mm (0.441 in.) B: 40 mm (1.57 in.)



17. INSTALL BACK WINDOW GLASS

- (a) Clean and shape the contact surface of the vehicle's body
 - (1) Using a knife, cut away any rough areas on the body.

HINT:

Leave as much adhesive on the body as possible.

(2) Clean the cut surface of the adhesive with a piece of shop rag saturated in cleaner.

- (b) Position the glass.
 - (1) Using a suction rubber, place the glass in the correct position.
 - (2) Check that all the contacting parts of the glass rim are perfectly even.
 - (3) Place reference marks between the glass and body.

NOTICE:

Check that the stoppers are attached to the body correctly.

HINT:

When reusing the glass, check and correct the reference mark's positions.


- (4) Remove the glass.
- (c) Coat the contact surface of the back door with Primer M.
- (d) Using a bursh, coat Primer M to the exposed part of the contact surface on the vehicle side with Primer M.

NOTICE:

- Dry the primer coating for 3 minutes or more.
- Do not coat the adhesive with Primer M.
- Do not apply too much Primer.
- (e) Coat the contact surface of the glass with Primer G.
 - (1) Using a brush or sponge, coat the edge of the glass and the contact surface with Primer G.

NOTICE:

- Dry the primer coating for 3 minutes or more.
- Do not apply too much primer.



- (f) Apply adhesive.
 - (1) Cut off the tip of the cartridge nozzle as shown in the illustration.

Part No. 08850-00801 or equivalent

HINT:

After cutting off the tip, use all adhesive within the time described in the table below.

Temperature	Tackfree time
35°C (95°F)	15 minutes
20°C (68°F)	100 minutes
5°C (41°F)	8 hours

- (2) Load the sealer gun with the cartridge.
- (3) Coat the glass with adhesive, as shown in the illustration.

a: 8 mm (0.31 in.) b: 12 mm (0.47 in.) c: 6.5 mm (0.256 in.)

- (g) Install the glass.
 - (1) Using a suction rubber, position the glass so that the reference marks are alined, and press it in gently along the rim.

NOTICE:

- Dry the primer coating for 3 minutes or more.
- Check that the stoppers are attached to the body correctly.
- Check the clearance between the body and glass.
 - (2) Lightly press the glass front surface for close contact.
 - (3) Using a scraper, remove any excess or protruding adhesive.

HINT:

Apply adhesive on the glass rim.

18. INSTALL BACK WINDOW MOULDING OUTSIDE

- (a) Install a new windshield moulding to the windshield glass before the adhesive has hardened.
- (b) Hold the windshield glass in place securely with protective tape or equivalent until the adhesive has completely hardened.
- (c) Using a scraper, remove any excess or protruding adhesive before the adhesive has hardened.

NOTICE:

Take care not to drive the vehicle during the time described in the table below.

Temperature	Tackfree time
35°C (95°F)	1.5 hours
20°C (68°F)	5 hours
5°C (41°F)	24 hours

19. WATER-LEAK CHECK AND REPAIREMENT

- (a) Conduct a leak test after the adhesive has completely hardened.
- (b) Seal any leak with sealant.