Service Hints

S14 Stop Light SW

2-1 : Closed with the brake pedal depressed

: Parts Location

	Code	See Page	Code	See Page	Code	See Page
	H16	42 (LHD)	N4	43 (LHD)	R14	43 (LHD)
1	J11	42 (LHD)	R13	43 (LHD)	S14	41 (LHD)

: Junction Block and Wire Harness Connector

Code See Page Junction Block and Wire Harnes		Junction Block and Wire Harness (Connector Location)		
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)		
2K 28 Floor Wire and Driver Side J/B (Lower Finish Panel)		Floor Wire and Driver Side J/B (Lower Finish Panel)		

: Ground Points

Code	See Page	Ground Points Location
BQ	64 (LHD)	Front Side of Rear Quarter Wheel House LH
BS	64 (LHD)	Lower Back Panel Center

: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B4	64 (LHD)	Floor Wire	B7	64 (LHD)	Floor Wire
B5	04 (LI ID)				