052ID-21

DIAGNOSTIC TROUBLE CODE CHART

1. TRANSPONDER KEY ECU DIAGNOSTIC TROUBLE CODE CHART

DTC No. (See Page)	Detection Item	Trouble Area
B2780 (05–2119)	Push Switch/Key Unlock Warning Switch Malfunction	Un–lock warning switch Wire harness Transponder key ECU assy
B2784 (05–2122)	Antenna Coil Open/Short	Wire harness Transponder key amplifier (Transponder key coil) Transponder key ECU assy
B2793 (05–2124)	Transponder Chip Malfunction	• Key
B2794 (05–2125)	Unmatched Encryption Code	• Key
B2795 (05–2126)	Unmatched Key Code	• Key
B2796 (05–2127)	No Communication in Immobiliser System	Key Transponder key amplifier (Transponder key coil) Wire harness Transponder key ECU assy
B2797 (05–2130)	Communication Malfunction No.1	Key Wire harness Transponder key amplifier Transponder key ECU assy
B2798 (05–2131)	Communication Malfunction No.2	• Key

2. ECM DIAGNOSTIC TROUBLE CODE CHART

NOTICE

The DTC for the immobiliser system is specified. If the other codes are output, check the DTC chart of the engine control system.

DTC No. (See Page)	Detection Item	Trouble Area
B2799 (05–2131)	Engine Immobiliser System Malfunction	Wire harness Transponder key ECU assy Transponder key amplifier (Transponder key coil) ECM