

## **DISPOSAL**

## HINT:

Dispose the RH side by the same procedures with the LH side.

- 1. DISPOSE SHOCK ABSORBER ASSY FRONT LH
- (a) Fully extend the shock absorber rod.
- (b) Using a drill, make a hole in the cylinder as shown in the illustration to discharge the gas inside.

## **CAUTION:**

- When drilling, chips may fly out, work carefully.
- The gas is colorless, odorless and non-poisonous.

CAMRY REPAIR MANUAL (RM915E)

2605Y-01