
WINDSHIELD WIPER SWITCH ASSY REPLACEMENT

6604V-01

1. REMOVE STEERING COLUMN COVER (See Page 50-9)



2. REMOVE WINDSHIELD WIPER SWITCH ASSY

- (a) Disconnect the connector.
- (b) Using a screwdriver, release the claw and pull out the windshield wiper switch assy.

NOTICE:

Pressing the claw hard breaks the claw.

HINT:

Tape the screwdriver tip before use.