PROBLEM SYMPTOMS TABLE

055VS−02

NOTICE:

Confirm the problem symptom and make an inspection depending on the applicable flowchart.

Problem symptom	Suspected area	See page
49 (No communication from double lock ECU more than 10 seconds.)	1. Door opening relay assy (Double lock ECU)	05−1278
	2. Wire harness	05−1278