
OUT SIDE MOULDING REPLACEMENT

760BV-03

HINT:

- Installation is in the reverse order of the removal. But, the installation is indicated only when it has a
 point.
- In the RH side, work in the same procedure as in the LH side.



1. REMOVE OUT SIDE MOULDING

(a) Using a heat light, heat the body moulding to 40 – 60°C (104 – 140°F).

NOTICE:

Do not heat the moulding excessively.

- (b) Tie both piano wire ends to wooden block or similar object.
- (c) Scrape the adhesive tape off by pulling the piano wire as shown in the illustration.

NOTICE:

- If reusing the moulding, take care not to damage the moulding.
- Do not damage the body.

2. INSTALL OUT SIDE MOULDING

(a) Using a heat light, heat the body mounting surface to 40 – 60°C (104 – 140°F).

NOTICE:


Do not heat the body excessively.

- (b) Remove the protective tape from the body.
- (c) Wipe off the stains with cleaner.
- (d) Clean the moulding (if reusing the moulding).
 - (1) Using a heat light, heat the body moulding to $20 30^{\circ}$ C ($68 86^{\circ}$ F).

NOTICE:

Do not heat the body excessively.

- (2) Remove the adhesive tape from the moulding.
- (3) Wipe off the stains with cleaner.
- (4) Apply new adhesive tape to the moulding as shown in the illustration.



(e) Using a heat light, heat the body and moulding.


HINT:

• Body: 40 – 60°C (104 – 140°F)

Moulding: 20 – 30°C (68 – 86°F)

NOTICE:

Do not heat the body excessively.



- (f) Lift the moulding release sheet from the face moulding. **NOTICE:**
 - When the moulding release sheet is removed, take care that no dirt or no dust can get onto the uncoated area
 - Do not apply excessive force onto the moulding, but steady pressure with your thumbs.