## PANEL SWITCH DOES NOT FUNCTION

## **INSPECTION PROCEDURE**

- 1 CHECK SWITCH
- (a) Check the switch
  - (1) Check that the switch is not pressed double by the foreign objects near the radio receiver switch. **Standard: No foreign objects**

NG > REMOVE FOREIGN OBJECT

OK

- 2 DISPLAY CHECK MODE
- (a) Inspect the display
  - (1) Boot the diagnosis, preform "Panel Switch Check" to check that the function is normal.

Standard: The function is normal

OK NORMAL

NG

**CHECK AND REPLACE RADIO RECEIVER ASSY**