
HEADLAMP DIMMER SWITCH ASSY REPLACEMENT

650BT-02

1. REMOVE STEERING COLUMN COVER (See Page 50-9)



2. REMOVE HEADLAMP DIMMER SWITCH ASSY

- (a) Disconnect the connector.
- (b) Using a screwdriver, release the claw and pull out the headlight dimmer switch assy.

NOTICE:

Pressing the claw hard breaks the claw.

HINT:

Tape the screwdriver tip before use.