MAP SCREEN DISPLAYED DOES NOT APPEAR (DISC CAUTOIN SCREEN DOES NOT CHANGE)

INSPECTION PROCEDURE

- 1 TAKE APPROPRIATE MESURES ACCORDING TO CAUTION SCREEN
- (a) Take appropriate measures according to caution screen.

CAUTION SCREEN

CAUTION MESSAGE	CAUSE	CORRECTIVE ACTION
Cover is open. Please close disc cover before using system.	The cover of the map disc slot is open.	Close the cover.
No disc detected. Insert map disc.	No map disc is inserted.	Insert a proper map disc.
No disc detected. Insert map disc. Check flaw or dirt on disc.	Cannot read correctly due to flaw or dirt.	Insert a correct map disc.
Disc read error. Check disc.	Something other than map disc i s inserted.	Insert a correct map disc.
Disc read error due to hight tempetature.	Pick-up part of the player is heated to a high temperature.	Stop the vehicle at a shaded cool place and turn the ignition switch OFF. When confirming that the temperature of the navigation ECU has been lowered, turn the ignition switch ON.
Disc read error. Consult dealer/sshop.	Player cannot read map disc temporarily.	Turn the IG switch from OFF to ON. (*1)

^{*1:} If the same "CAUTION MESSAGE" is displayed again even after turning the ignition switch to ON, replace the navigation ECU.

STANDARD: Correctly functions.

ОК	NORMAL
	110111111112

NG

2 | REPLACE DISC PLAYER DISC

NG

CHECK AND REPLACE NAVIGATION ECU